

Typ	Fluke Industrial				
Fluke Test Tools					
Digital Multimeters					
110 Series Multimeters					
Fluke 113	True RMS Multimeter	3088053	FLUKE-113 EUR,UTILITY MDMMS	FL11X	00 95969 43629 8
Fluke 114	True RMS Multimeter	2583552	FLUKE-114 EUR,ELECTRICDMMS	FL11X	00 95969 34479 1
Fluke 115	True RMS Multimeter	2583583	FLUKE-115 EUR,TRUE RMSDMMS	FL11X	00 95969 34481 4
Fluke 116	True RMS Multimeter	2583601	FLUKE-116 EUR,HVAC TRLDMMMS	FL11X	00 95969 34483 8
Fluke 117	True RMS Multimeter	2583647	FLUKE-117 EUR,ELECTRICDMMS	FL11X	00 95969 34485 2
Fluke 117/322	Electrician's Combo Kit	2583699	FLUKE-117/322 EUR,ELEC'DMMS	FL11X	00 95969 34488 3
C50	Soft Meter Case	762823	C50,CARRYING CASE ACC	CASE	00 95969 00987 4
170 Series Multimeters					
Fluke 175	True RMS Multimeter	1592901	FLUKE-175 EGFID,True RMDMMS	FL17X	00 95969 09592 1
Fluke 177	True RMS Multimeter	1592874	FLUKE-177 EGFID,True RMDMMS	FL17X	00 95969 09589 1
Fluke 179	True RMS Multimeter	1592842	FLUKE-179 EGFID,True RMDMMS	FL17X	00 95969 09586 0
Fluke 179/EDA2 Kit	Electronics Combo Kit	2718166	FLUKE-179/EDA2,ELECTRCDMMS	FL17X	00 95969 36279 5
Fluke 179/MAG2 Kit	Industrial Combo Kit	2718182	FLUKE-179/MAG2,ELECTRIDMMS	FL17X	00 95969 36281 8
Fluke 179/TPAK	179/ToolPak Combo Kit	2069064	FLK-179/TPAK EGFID,FLUKDMMS	FL17X	00 95969 23644 7
Fluke 179/61 Kit	Multimeter and Infrared Thermometer Combo Kit	2134644	FLUKE-179/61 EUR,IND D'DMMS	FL17X	00 95969 25544 8
C90	Soft Meter Case	466029	C90,CARRYING CASE ACC	CASE	00 95969 00353 7
280 Series Multimeters					
Fluke 287	True-RMS Electronic Logging Multimeter	2740201	FLUKE-287, TRUE-RMS ELIDMMS	FL28X	00 95969 36993 0
Fluke 287/FVF	Electronic Logging Multimeter and Software Combo Kit	3340186	FLUKE-287/FVF,TRUE-RMSDMMS	FL28X	00 95969 46978 4
Fluke 289	True-RMS Industrial Logging Multimeter	2675778	FLUKE-289, TRUE-RMS INIDMMS	FL28X	00 95969 35410 3
Fluke 289/FVF	Industrial Logging Multimeter and Software Combo Kit	3036206	FLUKE-289/FVF,TRUE-RMSDMMS	FL28X	00 95969 41714 3
C280	Soft Meter Case	3182785	C280,CARRYING CASE, POACC	CASE	00 95969 44380 7
20 Series Multimeters					
Fluke 233	True RMS Remote Display Multimeter	3469334			0 95969 49817 3
Fluke 28 II	True RMS Waterproof & dustproof IP67 multimeter	3301271			0 95969 46265 5
Fluke 27 II	Waterproof & dustproof IP67 multimeter	3307768			0 95969 46171 9
Fluke 27	Multimeter	739169	FLUKE-27 YEL,MULTIMETEDMMS	FL2X	00 95969 00943 0
C25	Soft Meter Case	681114	C25,SOFT CASE FOR FLUKACC	CASE	00 95969 00637 8
70 Series Multimeters					
Fluke 77 IV	Multimeter	2727486	FLUKE-77-4,INDUSTRIAL DMMS	FL7X	00 95969 36523 9
C90	Soft Meter Case	466029	C90,CARRYING CASE ACC	CASE	00 95969 00353 7
80 Series Multimeters					
Fluke 83V	Multimeter	2075004	FLUKE-83-5, INDUSTRIAL DMMS	FL8X	00 95969 24525 8
Fluke 87V	True RMS Multimeter	2074974	FLUKE-87-5, INDUSTRIAL DMMS	FL8X	00 95969 24524 1

Typ	Fluke Industrial				
Fluke 87V/E2 Kit	Industrial Electrician Combo Kit	2670150	FLUKE-87-5/E2 KIT,INDUSDMMS	FL8X	00 95969 35321 2
Fluke 87V Ex	Intrinsically Safe True RMS Multimeter	2547226	FLUKE-87-5-EX,INTRINSICDMMS	FL8X	00 95969 32772 5
Fluke 87V/I410	Combo Kit for Industrial Applications	3026714	FLUKE-87V/I410,FLUKE-87DMMS	FL8X	00 95969 41457 9
C25	Soft Meter Case	681114	C25,SOFT CASE FOR FLUKACC	CASE	00 95969 00637 8
Bench Multimeters					
Fluke 8808A	5.5 Digit Multimeter	2802372	8808A 220V,5.5 DIGIT PRIGPT	88DMM	00 95969 39352 2
Fluke 8808A/SU	5.5 Digit Multimeter (software & cable)	2802459	8808A/SU 220V,5.5 DIGIT GPT	88DMM	00 95969 39360 7
Fluke 8808A/TL	5.5 Digit Multimeter, 2X4W Test Lead Kit	3111085	8808A/TL 220V,5.5 DIGIT GPT	88DMM	00 95969 44152 0
Fluke 8845A/C	6.5 Digit Precision Multimeter 35ppm, NIST Traceable Cal Cert with data	2720674	8845A 220V, 6.5 DIGIT PRGPT	88DMM	00 95969 34430 2
Fluke 8845A/CSU	6.5 Digit Precision Multimeter (incl. software + cable)	2722675	8845A/SU 220V,6.5 DIGIT GPT	88DMM	00 95969 35391 5
Fluke 8846A/C	6.5 Digit Precision Multimeter 24ppm, NIST Traceable Cal Cert with data	2720707	8846A 220V, 6.5 DIGIT PRGPT	88DMM	00 95969 34433 3
Fluke 8846A/CSU	6.5 Digit Precision Multimeter (incl. software + cable)	2722701	8846A/SU 220V,6.5 DIGIT GPT	88DMM	00 95969 35396 0
884X-CASE	Hard Case (8845A/8846A)	2675552	884X-CASE,HEAVY DUTY EGPT	88DMM	00 95969 35409 7
884X-ETH	Ethernet Interface Cable	2675487	884X-ETH,ETHERNET INTEGPT	88DMM	00 95969 35403 5
884X-RTD	100 OHM RTD Temperature Probe	2675468	884X-RTD,100 OHM RTD 1GPT	88DMM	00 95969 35401 1
884X-SHORT	4-wire short	2653346	884X-SHORT,4 WIRE SHOIGPT	88DMM	00 95969 35286 4
884X-USB	USB to RS232 Cable Adapter	2675479	884X-USB,USB TO RS232 (GPT	88DMM	00 95969 35402 8
884X-512M	USB Memory 512 MB	2675529	884X-512M,USB MEMORY GPT	88DMM	00 95969 35407 3
884X-1G	USB Memory 1 GB	2675534	884X-1G,USB MEMORY 1 (GPT	88DMM	00 95969 35408 0
8845A-EFPT	Extended Fine Point Tip Adapter Set	2742690	8845A-EFPT,EXTENDED FIGPT	88DMM	00 95969 37054 7
8845A-TPIT	Test Probe IC Tip Set	2742683	8845A-TPIT,TEST PROBE 1GPT	88DMM	00 95969 37053 0
FVF-UG	FlukeView Forms Upgrade	1576741	FVF-UG,FLUKEVIEW FORMACC	FLSW	00 95969 09046 9
FVF-SC4	FlukeView Forms Software + Cable (8845A/8846A)	2687335	FVF-SC4,FLUKEVIEW FORMACC	FLSW	00 95969 36181 1
FVF-SC5	FlukeView Forms Basic (8845A/8846A)	2791314	FVF-SC5,FLUKEVIEW FORMACC	FLSW	00 95969 39079 8
RS43	RS232 Cable (2 m)	946470	RS43,SERIAL INTERFACE (DATA	HYDRA	00 95969 02525 6
TL2X4W-PTII	2x4 Wire Ohms Test Lead 2 mm Probe Tip	2826215	TL2X4W-PTII,2X4 WIRE OIGPT	88DMM	00 95969 40011 4
TL2x4W-TWZ	2X4-Wire Ohms Tweezers Test Leads	2723629	TL2X4W-TWZ,2X4 WIRE OGPT	88DMM	00 95969 36412 6
Y8021	IEEE-488 Shielded Interface Cable 1m	708289	Y8021,IEEE-488 SHIELDECALIB	CACCS	00 95969 08355 3
Y8022	IEEE-488 Shielded Interface Cable 2m	708297	Y8022,IEEE-488 SHIELDECALIB	CACCS	00 95969 08356 0
Y8846S	Rack mount kit single (8845A/8846A)	2675518	Y8846S,RACK MOUNT KIT GPT	88DMM	00 95969 35406 6
Y8846D	Rack mount kit dual (8845A/8846A)	2771721	Y8846D,RACK MOUNT KIT GPT	88DMM	00 95969 37868 0
FVF-SC3	FlukeView Forms Software + Cable (Fluke 45)	1675167	FVF-SC3,FLUKEVIEW FORMACC	FLSW	00 95969 13543 6
Automotive Meters					
Fluke 88V/A	Automotive Meter Combo Kit	2117440	FLUKE-88-5/A KIT,AUTOMDMMS	FL8X	00 95969 24907 2
Clamp Meters					
Fluke 321	Clamp Meter	1613429	FLUKE-321,400AMP, AC CLEPROD	CLAMP	00 95969 10564 4

Typ	Fluke Industrial				
Fluke 322	Clamp Meter	1613434	FLUKE-322,400AMP, 40AMEPROD	CLAMP	00 95969 10565 1
Fluke 333	Clamp Meter	2412445	FLUKE-333A,400 AMP AC IEPROD	CLAMP	00 95969 28660 2
Fluke 334	Clamp Meter	2412438	FLUKE-334A,600 AMP AC IEPROD	CLAMP	00 95969 28659 6
Fluke 335	True RMS Clamp Meter	2412423	FLUKE-335A,600 AMP TRUEPROD	CLAMP	00 95969 28658 9
Fluke 336	True RMS Clamp Meter	2412414	FLUKE-336A,600 AMP TRUEPROD	CLAMP	00 95969 28657 2
Fluke 337	True RMS Clamp Meter	2411216	FLUKE-337A,1000 AMP TR EPROD	CLAMP	00 95969 28561 2
Fluke 353	AC/DC True RMS Clamp Meter	2840252	FLUKE-353,AC/DC True RMEPROD	LCLMP	00 95969 40119 7
Fluke 355	AC/DC True RMS Clamp Meter	2840265	FLUKE-355,AC/DC True RMEPROD	LCLMP	00 95969 40120 3
Fluke 381	Remote Display 1000A True RMS Clamp with IFlex	3610452	FLUKE-381, REMOTE DISP EPROD	CLAMP	00 95969 53748 3
Fluke 376	1000A True RMS AC/DC Clamp with IFlex	3790573	FLUKE-376/E,1000A TRMS EPROD	CLAMP	00 95969 55984 3
Fluke 375	600A True RMS AC/DC Clamp	3790586	FLUKE-375/E,600A TRMS EPROD	CLAMP	00 95969 55985 0
Fluke 374	600A True RMS AC/DC Clamp	3790599	FLUKE-374/E,600A TRMS EPROD	CLAMP	00 95969 55986 7
Fluke 373	600A True RMS AC Clamp Meter	3790564	FLUKE-373/E,600A TRMS EPROD	CLAMP	00 95969 55983 6
Fluke 365	Detachable 200A True RMS AC/DC Clamp	3790607	FLUKE-365/E,DETACHABLE EPROD	CLAMP	00 95969 55987 4
Fluke I2500-18	IFlex 2500A probe 18in – 45,7 cm	3676405	FLUKE-I2500-18, IFLEX 25 EPROD	CLAMP	00 95969 55969 0
Fluke I2500-10	IFlex 2500A probe 10IN – 25,4 cm	3676410	FLUKE-I2500-10, IFLEX 25 EPROD	CLAMP	00 95969 55970 6
Fluke 360	Leakage Current Clamp Meter	2726380	FLUKE-360,LEAKAGE CURFEPROD	CLAMP	00 95969 36450 8
Fluke 902	True RMS Clamp Meter (HVAC)	2556988	FLUKE-902, TRUE RMS HV.IAD	IA90	00 95969 33214 9
Fluke 62/322/1AC	IR Thermometer, Clamp Meter and Voltage Detector Kit	2772510	FLUKE-62/322/1AC,KIT WITEMP	FL6X	00 95969 37904 5
Fluke 117/322	Electrician's Combo Kit	2583699	FLUKE-117/322 EUR,ELEC DMMS	FL11X	00 95969 34488 3
H3	Holster (330 Series)	1608458	H3,HOLSTER WITH ACCESACC	CASE	00 95969 10272 8
Electrical Testers					
Fluke 1AC II	Volt Alert	2432971	FLUKE-1AC-E2-II,ACV DETEPROD	VALRT	00 95969 29082 1
Fluke 1AC II 5PK	Volt Alert 5-pack	2433056	FLK-1AC-E1-II-5PK,VOLT AEPROD	VALRT	00 95969 29090 6
Fluke 2AC VoltAlert	Volt Alert 2AC	3611985	FLK2AC/200-1000VCL,ACVEPROD	VALRT	0 95969 53772 8
Fluke 2AC 5PK	Volt Alert 2AC 5-pack	3806493	FLK2AC/200-1000V5L,VOL EPROD	VALRT	0 95969 56374 1
Fluke T5-600	Electrical Tester	659612	T5-600 EUR1,ELECTRICAL EPROD	T5	00 95969 05950 3
Fluke T5-1000	Electrical Tester	659570	T5-1000 EUR1,ELECTRICAL EPROD	T5	00 95969 05946 6
Fluke T5-H5-1AC II Kit	Electrical Tester Kit with Holster and 1AC	2098657	T5-H5-1AC KIT/EUR,T5-10 EPROD	T5	00 95969 24266 0
Fluke T5-600/62/1AC	Electrical Tester, IR Thermometer and Voltage Detector Kit	2844485	T5-600/62/1AC-E,KIT W/s EPROD	T5	0 95969 40197 5
Fluke T50	Voltage/Continuity Tester	2435014	T50,VOLTAGE TESTER EPROD	TPOLE	00 95969 29132 3
Fluke T100	Voltage/Continuity Tester	2396724	T100,VOLTAGE/CONTINUITY EPROD	TPOLE	00 95969 28317 5
Fluke T120	Voltage/Continuity Tester	2396736	T120,VOLTAGE/CONTINUITY EPROD	TPOLE	00 95969 28318 2
Fluke T140 VDE	Voltage/Continuity Tester	2544627	T140,VOLTAGE/CONTINUITY EPROD	TPOLE	00 95969 28319 9
Fluke 2042	Cable Locator (Transmitter + Receiver)	2435038	FLUKE-2042,CABLE LOCATEPROD	ETEST	00 95969 29134 7
Fluke 2042T	Cable Locator Transmitter	2435045	FLUKE-2042T,CABLE LOCAEPROD	ETEST	00 95969 29135 4
Fluke 9040 EUR	Phase Rotation Indicator	4014969	FLUKE-9040EUR,PHASE RCEPROD	ETEST	0 95969 59947 4

Typ	Fluke Industrial				
Fluke 9062	Motor and Phase Rotation Indicator	2435077	FLUKE-9062,CONTACTLES:EPROD	ETEST	00 95969 29138 5
LVD1	Volt Light	2139415	LVD1,VOLT LIGHT ACC	LIGHT	00 95969 25745 9
LVD2	Volt Light	2740300	LVD2,VOLT LIGHT ACC	LIGHT	00 95969 36997 8
RLD2	Leak Detector Flashlight	3387163	RLD2,LEAK DETECTOR FL/IAD	GAST	00 95969 48492 3
H5	Electrical Tester Holster (Fluke T5)	649365	H5,HOLSTER,BELT,ACCES:ACC	CASE	00 95969 05719 6
Laser Distance Meters					
Fluke 411D	Laser Distance Meter up to 30m	3326414	FLUKE-411D,LASER DISTA TEMP	DIST	00 95969 46738 4
Fluke 411D/62 Kit	Laser Distance Meter and IR Thermometer Kit	3446013	FLUKE-411D/62,411D LASI TEMP	DIST	00 95969 49372 7
Fluke 416D	Laser Distance Meter up to 60m, backlight	3326423	FLUKE-416D,LASER DISTA TEMP	DIST	00 95969 46739 1
Fluke 421D	Laser Distance Meter up to 100m, tilt sensor	3480795	TEMP	DIST	00 95969 50051 7
Insulation Testers					
Fluke 1503	Insulation Tester	2427883	FLUKE-1503,INSULATION EPROD	SINSU	00 95969 28866 8
Fluke 1507	Insulation Tester	2427890	FLUKE-1507,INSULATION EPROD	SINSU	00 95969 28867 5
Fluke 1550C	5kV Insulation Tester	3665021	EPROD	SINSU	0 95969 55091 8
Fluke 1550C/KIT	5kV Insulation Tester Kit	3665127	EPROD	SINSU	0 95969 55098 7
Fluke 1555	10kV Insulation Tester	3665056	EPROD	SINSU	0 95969 55092 5
Fluke 1555/KIT	10kV Insulation Tester Kit	3665111	EPROD	SINSU	0 95969 55097 0
Fluke 1550B	MegOhmMeter – obsolete	2095847	FLUKE-1550B,5KV MEGOH EPROD	SINSU	00 95969 24161 8
Fluke 1577	Insulation Multimeter	2157280	FLUKE-1577,INSULATION EPROD	SINSU	00 95969 26296 5
Fluke 1587	Insulation Multimeter	2157271	FLUKE-1587,INSULATION EPROD	SINSU	00 95969 26295 8
Fluke 1587T	Insulation Multimeter (Telecom)	2517605	FLUKE-1587 T,INSULATIOI EPROD	SINSU	00 95969 31976 8
Fluke 1587ET	Advanced Electrical Troubleshooting Kit	2509646	FLUKE-1587 ET,ADVANCEI EPROD	SINSU	00 95969 30875 5
Fluke 1587MDT	Advanced Motor & Drive Troubleshooting Kit	2509654	FLUKE-1587 MDT,ADVANCEPROD	SINSU	00 95969 30876 2
FVF-Basic	FlukeView Forms Basic + IR USB cable (189, 287, 289, 789, 1550B)	2396957	FVF-BASIC,FLUKEVIEW FOACC	FLSW	00 95969 28323 6
FVF-SC2	FlukeView Forms Software + IR USB-Cable (180 Series, 1653, 789, 1550)	1576734	FVF-SC2,FLUKEVIEW FORIACC	FLSW	00 95969 09048 3
IR189USB	IR Cable - USB (280/180 Series, 1653, 789, 1550B)	2428108	IR189USB, USB CABLE FOIACC	FLSW	00 95969 28870 5
Installation Testers					
Fluke 1651B	Multifunction Installation Tester	3277770	FLUKE-1651B-05,INSTALL/EPROD	INSTL	00 95969 46074 3
Fluke 1652B	Multifunction Installation Tester	3277835	FLUKE-1652B-05,INSTALL/EPROD	INSTL	00 95969 46080 4
Fluke 1653B	Multifunction Installation Tester	3277939	FLUKE-1653B-05,INSTALL/EPROD	INSTL	00 95969 46090 3
ES165X	Earth Spike Test Kit	2104706	ES165X, EARTH SPIKE TESEPROD	INSAC	00 95969 24507 4
FVF-SC2	FlukeView Forms Software + IR USB-Cable (180 Series, 1653, 789, 1550)	1576734	FVF-SC2,FLUKEVIEW FORIACC	FLSW	00 95969 09048 3
IR189USB	IR Cable - USB (280/180 Series, 1653, 789, 1550B)	2428108	IR189USB, USB CABLE FOIACC	FLSW	00 95969 28870 5
MTC77	Mains Test Cord (CEE 7 7 Schuko)	2457421	MTC77,MAINS TEST CORDACC	MISC	00 95969 29377 8
TP165X	Remote Control Probe (1650 Series)	2107742	TP165X,TEST PROBE WITHACC	LEAD	00 95969 24594 4
TL165X	Standard Test Lead Set (1650 Series)	2107756	TL165X,STD TL SET W/LE/ACC	LEAD	00 95969 24595 1
ZERO ADAPTER	Zero adapter for 165xB	3261925	ZERO ADAPTER,ZERO ADAEPROD	INSTL	00 95969 46094 1

Typ	Fluke Industrial				
Fluke 1654B-01	Fluke 1654B-01 Installation Tester	3792794	FLUKE-1654B-01, INSTALLEPROD	INSTL	00 95969 56035 1
Fluke 1654B-02	INSTALLATION TESTER W/ RCD TYPE B, MEM, GER,SCHUKO	3792802	FLUKE-1654B-02, INSTALLEPROD	INSTL	00 95969 56036 8
Fluke 1654B-05	INSTALLATION TESTER W/ RCD TYPE B, MEM, SCHUKO	3792833	FLUKE-1654B-05, INSTALLEPROD	INSTL	00 95969 56039 9
Fluke 1654B-06	INSTALLATION TESTER W/RCD TYPE B, MEM, SWISS CORD	3792840	FLUKE-1654B-06, INSTALLEPROD	INSTL	00 95969 56040 5
Fluke 1652C-05	1652C Installation Tester	3834528	FLUKE-1652C-05, INSTALLEPROD	INSTL	00 95969 56581 3
Portable Appliance Testers					
Earth Ground Testers					
Fluke 1621	Earth Ground Tester	2840276	FLUKE-1621,EARTH GROU EPROD	LGEO	00 95969 40121 0
Fluke 1623	Basic GEO Earth Ground Tester	2571250	FLUKE-1623,BASIC GEO E/EPROD	LGEO	00 95969 34032 8
Fluke 1623 Kit	Basic GEO Earth Ground Tester Kit	2571245	FLUKE-1623 KIT,BASIC GEEPROD	LGEO	00 95969 34031 1
Fluke 1625	Advanced GEO Earth Ground Tester	2571664	FLUKE-1625,ADVANCED GIEPROD	LGEO	00 95969 34069 4
Fluke 1625 Kit	Advanced GEO Earth Ground Tester Kit	2571261	FLUKE-1625 KIT,ADVANCE EPROD	LGEO	00 95969 34033 5
Fluke 1630	Earth Ground Clamp Meter	2729698	FLUKE-1630,EARTH GROU EPROD	LGEO	00 95969 36556 7
EI-1623	Selective/stakeless clamp set (1623)	2577115	EI-1623,SELECTIVE/STAKE EPROD	LGEO	00 95969 34423 4
EI-1625	Selective/stakeless clamp set (1625)	2577126	EI-1625,A604510304,SELEEPROD	LGEO	00 95969 34424 1
EI-162BN	320 mm Split Core Transformer	2577159	EI-162BN,A680506211,12. EPROD	LGEO	00 95969 34427 2
ES-162P3	Stake/reel set for 3-pole measurement	2577091	ES-162P3,A604510302,ST/EPROD	LGEO	00 95969 34421 0
ES-162P4	Stake/Reel Set for 4 pole measurements	2577103	ES-162P4,A604510301,ST/EPROD	LGEO	00 95969 34422 7
GEO CABLE-REEL 25M	Ground Earth Cable Reel 25M Wire	2539100	GEO CABLE-REEL 25M,A60 EPROD	LGEO	00 95969 32435 9
GEO CABLE-REEL 50M	Ground Earth Cable Reel 50M Wire	2539117	GEO CABLE-REEL 50M,A60 EPROD	LGEO	00 95969 32436 6
GEO EARTH STAKE	Ground Earth Stake	2539121	GEO EARTH STAKE,A6045 EPROD	LGEO	00 95969 32437 3
Indoor Air Quality Tools					
Fluke 922	Airflow Meter	2679822	FLUKE-922, AIRFLOW METIAD	IA92	00 95969 35531 5
Fluke 922/Kit	Airflow Meter Kit	2679831	FLUKE-922/KIT, AIRFLOW IAD	IA92	00 95969 35532 2
Fluke 971	Temperature Humidity Meter	2418208	FLUKE-971, TEMPERATUR IAD	IA97	00 95969 28751 7
Fluke 975	AirMeter	2519364	FLUKE-975, AIRMETER IAD	IA97	00 95969 32028 3
Fluke 975V	AirMeter with Velocity	2666111	FLUKE-975V, AIRMETER WIAD	IA97	00 95969 35309 0
Fluke 983	Particle Counter	2414646	FLUKE-983,PARTICLE COUIAD	IA98	00 95969 28697 8
Fluke CO-220	Carbon Monoxide Meter	664711	FLUKE-CO-220,CARBON MIAD	GAST	00 95969 06180 3
CO-205	Aspirator Kit	664714	FLUKE-CO-205,CARBON MIAD	GAST	00 95969 06181 0
975CK	AirMeter Calibration Kit	2671707	FLUKE-975CK, AIR METER,IAD	IA97	00 95969 35328 1
975R	Regulator	2770767	FLUKE-975R, REGULATOR,IAD	IA97	00 95969 39408 6
975VP	Air Velocity Probe	2631538	FLUKE-975VP, AIR VELOC IAD	IA97	00 95969 34632 0
PT12	Pitot Tube, 12"	2740212	PT12,PITOT TUBE, 12 INCIAD	IA92	00 95969 36994 7
Digital Thermometers					
Fluke 51 II	Thermometer	1281142	FLUKE-51-2 50HZ,SINGLE TEMP	FL5X	00 95969 07765 1
Fluke 52 II	Thermometer	1281139	FLUKE-52-2 50HZ,DUAL INTEMP	FL5X	00 95969 07764 4

Typ	Fluke Industrial				
Fluke 53 II	Thermometer	1281121	FLUKE-53-2 50HZ,SINGLE TEMP	FL5X	00 95969 07763 7
Fluke 54 II	Thermometer	1281117	FLUKE-54-2 50HZ,DUAL INTEMP	FL5X	00 95969 07762 0
Fluke 61	Infrared Thermometer	1643896	FLUKE-61,IR THERMOMETEMP	FL6X	00 95969 11903 0
Fluke 62	Mini IR Thermometer	2433868	FLUKE-62,MINI IR THERM(TEMP	FL6X	00 95969 29112 5
Fluke 63	Infrared Thermometer	2148281	FLUKE-63,INFRARED THEFTEMP	FL6X	00 95969 26114 2
Fluke 66	Infrared Thermometer	2148296	FLUKE-66,ADJUSTABLE INTEMP	FL6X	00 95969 26115 9
Fluke 68	Infrared Thermometer	2148308	FLUKE-68,ADJUSTABLE INTEMP	FL6X	00 95969 26116 6
Fluke 561	Multipurpose Thermometer	2558118	FLUKE-561, IR THERMOMETEMP	FL560	00 95969 33253 8
Fluke 566	Multipurpose Thermometer	2837799	FLUKE-566,IR THERMOMETEMP	FL560	00 95969 40036 7
Fluke 568	Multipurpose Thermometer	2837806	FLUKE-568,IR THERMOMETEMP	FL560	00 95969 40037 4
Fluke 572	Precision IR Thermometer	2436583	FLUKE-572,PRECISION IR TEMP	FL570	00 95969 29157 6
Fluke 572CF	Precision IR Thermometer (close focus option)	2436601	FLUKE-572-CF,PRECISION TEMP	FL570	00 95969 29159 0
Fluke 574	Precision IR Thermometer	2436612	FLUKE-574,PRECISION IR TTEMP	FL570	00 95969 29160 6
Fluke 574CF	Precision IR Thermometer (close focus option)	2436647	FLUKE-574-CF,PRECISION ITEMP	FL570	00 95969 29163 7
Fluke 576	Precision IR Thermometer	2436658	FLUKE-576,PRECISION PHTEMP	FL570	00 95969 29164 4
Fluke 576CF	Precision IR Thermometer (close focus option)	2436673	FLUKE-576-CF,PREC PHOTTEMP	FL570	00 95969 29166 8
Fluke FP	FoodPro Thermometer	2644169	FLUKE-FP EU,FOODPRO CITEMP	FOODS	00 95969 34848 5
Fluke FP Plus	FoodPro Plus Thermometer	2477950	FLUKE-FP PLUS,FOODPRO TEMP	FOODS	00 95969 29870 4
FP Probe	Probe (FoodPro Plus Thermometer)	2477961	FP-PROBE,PROBE FOR FOICMARK	RFOOD	00 95969 29871 1
Fluke T5-600/62/1AC	Electrical Tester, IR Thermometer and Voltage Detector Kit	2772522	T5-600/62/1AC,KIT WITH EPROD	T5	00 95969 37905 2
Fluke 62/322/1AC	IR Thermometer, Clamp Meter and Voltage Detector Kit	2772510	FLUKE-62/322/1AC,KIT WITEMP	FL6X	00 95969 37904 5
AN5	Analog Data Cable (574, 576)	2437178	AN5,CABLE, ANALOG OUTIACC	MISC	00 95969 29170 5
C50	Soft Meter Case	762823	C50,CARRYING CASE ACC	CASE	00 95969 00987 4
C570	Soft Case (572, 574, 576)	2436565	C570,SOFT CASE, 57X SERACC	CASE	00 95969 29155 2
H6	Infrared Thermometer Holster (Fluke 63/65/68/561)	2152040	H6, IR-PISTOL-HOLSTER ACC	CASE	00 95969 26188 3
FVF-SC1	FlukeView Forms Software + Cable (Fluke 53II/54II/87 IV/89 IV)	1576285	FVF-SC1,FLUKEVIEW FORIACC	FLSW	00 95969 09044 5
80PR-60	RTD Temperature Probe (Fluke 66/68)	2148313	80PR-60, IR-PISTOL-RTD IACC	PRTPT	00 95969 26117 3
Thermal Imagers					
Fluke Ti9 Electrical	Thermal Imager For Electrical and Electro-Mechanical Applications, -20 / 3410250		FLK-TI9 9HZ, TI9 THERMATI	PTI	00 95969 49222 5
Fluke Ti10	Thermal Imager with IR fussion, -20 / 250°C	2822046	FLK-TI10 9HZ,TI10 9HZ THTI	PTI	00 95969 39945 6
Fluke Ti25	Thermal Imager with IR fussion, analytics, 160 x 120, -20 / 350°C	2823117	FLK-TI25 9HZ,TI25 9HZ THTI	PTI	00 95969 39956 2
Fluke Ti27	Thermal Imager with IR fussion, analytics, 240 x 180, -20 / 600°C	4000262			
Fluke Ti29	Thermal Imager with IR fussion, analytics, 280 x 210, -20 / 600°C	4000243			
Fluke Ti32	Thermal Imager with IR fussion, analytics, 320 x 240, -20 / 600°C	3405726			0 95969 49174 7
Fluke Ti40FT-20	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20 mm)	2648578	FLK-TI40FT-20,IR FLEXCAIISITI	FLXCM	00 95969 35038 9
Fluke Ti45FT-20	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20 mm)	2648396	FLK-TI45FT-20,IR FLEXCAIISITI	FLXCM	00 95969 35020 4
Fluke Ti50FT-20	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20 mm)	2649195	FLK-TI50FT-20,IR FLEXCAIISITI	FLXCM	00 95969 35100 3

Typ	Fluke Industrial				
Fluke Ti55FT-20	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20 mm)	2649053	FLK-TI55FT-20,IR FLXCAMISITI	FLXCM	00 95969 35086 0
Fluke Ti40FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20 mm), 7.5 Hz	2693940	FLK-TI40FT-20/7.5,IR FLXISITI	FLXCM	00 95969 36210 8
Fluke Ti45FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20 mm), 7.5 Hz	2791893	FLK-TI45FT-20/7.5,IR FLXISITI	FLXCM	00 95969 39099 6
Fluke Ti50FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20 mm), 7.5 Hz	2792030	FLK-TI50FT-20/7.5,IR FLXISITI	FLXCM	00 95969 39113 9
Fluke Ti55FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20 mm), 7.5 Hz	2792142	FLK-TI55FT-20/7.5,IR FLXISITI	FLXCM	00 95969 39124 5
Thermal Imagers Special Models					
Fluke Ti40FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20 mm)	2648617	FLK-TI40FT-10/20,IR FLEXISITI	FLXCM	00 95969 35042 6
Fluke Ti40FT-20/54	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20/54 mm)	2648494	FLK-TI40FT-20/54,IR FLEXISITI	FLXCM	00 95969 35030 3
Fluke Ti40FT-10/20/54	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20/54 mm)	2648642	FLK-TI40FT10/20/54,IR FLISITI	FLXCM	00 95969 35045 7
Fluke Ti45FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20 mm)	2648482	FLK-TI45FT-10/20,IR FLXCISITI	FLXCM	00 95969 35029 7
Fluke Ti45FT-20/54	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20/54 mm)	2648516	FLK-TI45FT-20/54,IR FLXCISITI	FLXCM	00 95969 35032 7
Fluke Ti45FT-10/20/54	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20/54 mm)	2648533	FLK-TI45FT10/20/54,IR FLISITI	FLXCM	00 95969 35034 1
Fluke Ti45FT/HT-20	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 20 mm)	2648923	FLK-TI45FT/HT-20,IR FLXISITI	FLXCM	00 95969 35073 0
Fluke Ti45FT/HT10/20	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 10.5/20 mm)	2694633	FLK-TI45FT/HT10/20,IR FLISITI	FLXCM	00 95969 36230 6
Fluke Ti45FT/HT20/54	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 20/54 mm)	2694640	FLK-TI45FT/HT20/54,IR FLISITI	FLXCM	00 95969 36231 3
Fluke Ti45FT/HT3LENS	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 10.5/20/54 mm)	2694657	FLK-TI45FT/HT3LENS,IR FISITI	FLXCM	00 95969 36232 0
Fluke Ti50FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20 mm)	2649238	FLK-TI50FT-10/20,IR FLXCISITI	FLXCM	00 95969 35104 1
Fluke Ti50FT-20/54	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20/54 mm)	2649250	FLK-TI50FT-20/54,IR FLXCISITI	FLXCM	00 95969 35106 5
Fluke Ti50FT-10/20/54	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20/54 mm)	2649277	FLK-TI50FT10/20/54,IR FLISITI	FLXCM	00 95969 35108 9
Fluke Ti55FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20 mm)	2649094	FLK-TI55FT-10/20,IR FLXCISITI	FLXCM	00 95969 35090 7
Fluke Ti55FT-10/20/54	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20/54 mm)	2649139	FLK-TI55FT10/20/54,IR FLISITI	FLXCM	00 95969 35094 5
Fluke Ti55FT-20/54	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20/54 mm)	2649117	FLK-TI55FT-20/54,IR FLEXISITI	FLXCM	00 95969 35092 1
Fluke Ti40FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20 mm), 7.5 Hz	2791785	FLK-TI40FT10/20/7.5,IR FISITI	FLXCM	00 95969 39088 0
Fluke Ti40FT20/54/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20/54 mm), 7.5 Hz	2791797	FLK-TI40FT20/54/7.5,IR FISITI	FLXCM	00 95969 39089 7
Fluke Ti40FT-3L/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20/54 mm), 7.5 Hz	2791805	FLK-TI40FT-3L/7.5,IR FLXISITI	FLXCM	00 95969 39090 3
Fluke Ti45FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20 mm), 7.5 Hz	2791887	FLK-TI45FT10/20/7.5,IR FISITI	FLXCM	00 95969 39098 9
Fluke Ti45FT20/54/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20/54 mm), 7.5 Hz	2791902	FLK-TI45FT20/54/7.5,IR FISITI	FLXCM	00 95969 39100 9
Fluke Ti45FT/HT20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 20 mm), 7.5 Hz	2791916	FLK-TI45FT/HT20/7.5,IR FISITI	FLXCM	00 95969 39101 6
Fluke Ti45FTHT10207.5	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 10.5/20 mm), 7.5 Hz	2791925	FLK-TI45FTHT10207.5,IR IISITI	FLXCM	00 95969 39102 3
Fluke Ti45FTHT20547.5	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 20/54 mm), 7.5 Hz	2791933	FLK-TI45FTHT20547.5,IR IISITI	FLXCM	00 95969 39103 0
Fluke Ti45FTHT/3L/7.5	IR FlexCam Thermal Imager (IR-Fusion, 1200°C, 10.5/20/54 mm), 7.5 Hz	2791940	FLK-TI45FTHT/3L/7.5,IR FISITI	FLXCM	00 95969 39104 7
Fluke Ti45FT-3L/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20/54 mm), 7.5 Hz	2791957	FLK-TI45FT-3L/7.5,IR FLXISITI	FLXCM	00 95969 39105 4
Fluke Ti50FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20 mm), 7.5 Hz	2792027	FLK-TI50FT10/20/7.5,IR FISITI	FLXCM	00 95969 39112 2
Fluke Ti50FT20/54/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 20/54 mm), 7.5 Hz	2792048	FLK-TI50FT20/54/7.5,IR FISITI	FLXCM	00 95969 39114 6

Typ	Fluke Industrial				
Fluke Ti50FT-3L/7.5	IR FlexCam Thermal Imager (IR-Fusion, 350°C, 10.5/20/54 mm), 7.5 Hz	2792053	FLK-TI50FT-3L/7.5,IR FLX:ISITI	FLXCM	00 95969 39115 3
Fluke Ti55FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20 mm), 7.5 Hz	2792139	FLK-TI55FT10/20/7.5,IR FIISITI	FLXCM	00 95969 39123 8
Fluke Ti55FT20/54/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 20/54 mm), 7.5 Hz	2792156	FLK-TI55FT20/54/7.5,IR FIISITI	FLXCM	00 95969 39125 2
Fluke Ti55FT-3L/7.5	IR FlexCam Thermal Imager (IR-Fusion, 600°C, 10.5/20/54 mm), 7.5 Hz	2792163	FLK-TI55FT-3L/7.5,IR FLX:ISITI	FLXCM	00 95969 39126 9
Thermal Imagers Building Diagnostics					
Fluke TiS	Thermal Imaging Scanner	3801034	FLK-TIS 9HZ TI	PTI	0 95969 56252 2
Fluke TiRx Inspector	Thermal Imager, -20 / 100°C	3410261	FLK-TIR1 9HZ,TIR1 9HZ TITI	PTI	00 95969 39957 9
Fluke TiR	Building Thermal Imager, IR fussion, -20 / 100°C	3032773	FLK-TIR2/FT-20,IR FLEXC/ISITI	FLXCM	00 95969 35115 7
Fluke TiR1	Building Thermal Imager, IR fussion, analytics, 160 x 120, -20 / 100°C	2823121	FLK-TIR2/FT-10/20,IR FLEISITI	FLXCM	00 95969 35118 8
Fluke TiR27	Building Thermal Imager, IR fussion, analytics, 240 x 180, -20 / 150°C	4000308			
Fluke TiR29	Building Thermal Imager, IR fussion, analytics, 280 x 210, -20 / 150°C	4000281			
Fluke TiR32	Building Thermal Imager, IR fussion, analytics, 320 x 240, -20 / 150°C	3433301			0 95969 49242 3
Fluke TiR2/FT-20	IR FlexCam Thermal Imager (IR-Fusion, 20 mm)	2649344	FLK-TIR3/FT-20,IR FLEXC/ISITI	FLXCM	00 95969 35374 8
Fluke TiR2/FT-10/20	IR FlexCam Thermal Imager (IR-Fusion - 10.5/20 mm)	2649371	FLK-TIR3/FT-10/20,IR FLEISITI	FLXCM	00 95969 39852 7
Fluke TiR3/FT-20	IR FlexCam Thermal Imager (IR-Fusion, 20 mm)	2674891	FLK-TIR4/FT-20,IR FLEXC/ISITI	FLXCM	00 95969 35375 5
Fluke TiR3/FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 10.5/20 mm)	2816113	FLK-TIR4/FT-10/20,IR FLEISITI	FLXCM	00 95969 39849 7
Fluke TiR4/FT-20	IR FlexCam Thermal Imager (IR-Fusion, 20 mm)	2674968	FLK-TIR2/FT-20/7.5,IR FL\ISITI	FLXCM	00 95969 39131 3
Fluke TiR4/FT-10/20	IR FlexCam Thermal Imager (IR-Fusion, 10.5/20 mm)	2816061	FLK-TIR2FT10/20/7.5,IR FISITI	FLXCM	00 95969 39130 6
Fluke TiR2/FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion - 20 mm), 7.5 Hz	2792214	FLK-TIR3/FT-20/7.5,IR FL\ISITI	FLXCM	00 95969 39133 7
Fluke TiR2FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion - 10.5/20 mm), 7.5 Hz	2792206	FLK-TIR3FT10/20/7.5,IR FISITI	FLXCM	00 95969 41371 8
Fluke TiR3/FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 20 mm), 7.5 Hz	2792238	FLK-TIR4FT-10/20/7.5,IR IISITI	FLXCM	00 95969 41374 9
Fluke TiR3FT10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 10.5/20 mm), 7.5 Hz	3016097	FLK-TIR4/FT-20/7.5,IR FL\ISITI	FLXCM	00 95969 39135 1
Fluke TiR4FT-10/20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 10.5/20 mm), 7.5 Hz	3016138	FLK-TIR1 9HZ,TIR1 9HZ TITI	PTI	00 95969 39957 9
Fluke TiR4/FT-20/7.5	IR FlexCam Thermal Imager (IR-Fusion, 20 mm), 7.5 Hz	2792250	FLK-TIR2/FT-20,IR FLEXC/ISITI	FLXCM	00 95969 35115 7
Thermal Imagers Accessories					
TI CAR CHARGER	Ti Car Charger (TiR/TiR1/Ti10/Ti20/Ti25)	3039779	TI-CAR CHARGER,CAR CH/TI	TIACC	00 95969 41756 3
TI-VISOR	Sun Visor	3374437	TI-VISOR,VISOR FOR TI10ISITI	TIACC	00 95969 48073 4
Ti20-RBP	Rechargeable Battery Pack (Ti20)	2577796	TI20-RBP,RECHARGEABLE TI	PTI	00 95969 34458 6
Ti1-RBP	Rechargeable Battery Pack (Ti9, Ti10, Ti25, TiR, TiRx, TiR1, TiS)	3524222	TI20-RBP,RECHARGEABLE TI	PTI	00 95969 34458 6
Ti-SBC	Battery Charger (IR FlexCam)	2648355	FLK-TI-SBC,104465,IR SM/ISITI	TIACC	00 95969 35016 7
104543	Car charger (IR FlexCam)	2648411	104543,VEHICLE ADAPTERISITI	TIACC	00 95969 35022 8
FLK-LENS/TELE1	Telephoto Infrared Lens	3441176	FLK-LENS/TELE1,INFRAREISITI	TIACC	00 95969 49350 5
FLK-LENS/WIDE1	Wide-angle Infrared Lens	3441183	FLK-LENS/WIDE1,INFRAREISITI	TIACC	00 95969 49351 2
FLK-TI-SBC3	Charging base (Ti32/TiR32)	3440352	FLK-TI-SBC3,SMART BATT ISITI	TIACC	00 95969 49370 3
FLK-TI-SBP3	Extra battery (Ti32/TiR32)	3440365	FLK-TI-SBP3,SMART BATT ISITI	TIACC	00 95969 49338 3
TI-TRIPOD	Tripod mount for Ti32, TiR32, Ti25, TiR1, Ti10, TiR, Ti9, TiRx, ...	3511872	TI-TRIPOD	0 95969 5:TIACC	

Typ	Fluke Industrial				
3950513	FLK-TI32-WIDE GOLD KIT	3950513	FLK-TI-SBP3,SMART BATT:ISITI	TIACC	00 95969 49338 3
3960778	FLK-TI32-TELE GOLD KIT	3960778	FLK-TI-SBP3,SMART BATT:ISITI	TIACC	00 95969 49338 3
3950524	FLK-TIR32-WIDE GOLD KIT	3950524	FLK-TI-SBP3,SMART BATT:ISITI	TIACC	00 95969 49338 3
3960784	FLK-TIR32-TELE GOLD KIT	3960784	FLK-TI-SBP3,SMART BATT:ISITI	TIACC	00 95969 49338 3
FLK-050-CLKT	FLK-050-CLKT,2 IN (50MM) C-RANGE IR WINDOW, KWIK TWIST	3460346	FLK-050-CLKT,2 IN (50MM)HAWK	CRNG	00 95969 49581 3
FLK-075-CLKT	FLK-075-CLKT,3 IN (75MM) C-RANGE IR WINDOW, KWIK TWIST	3460387	FLK-075-CLKT,3 IN (75MM)HAWK	CRNG	00 95969 49585 1
FLK-100-CLKT	FLK-100-CLKT,4 IN (100MM) C-RANGE IR WINDOW, KWIK TWIST	3460439	FLK-100-CLKT,4 IN (100MM)HAWK	CRNG	00 95969 49590 5
FLK-075-CLKTO	FLK-075-CLKTO,3 IN (75MM) C-RANGE,INDOOR MEDIUM VOLTAGE,IR V	3460611	FLK-075-CLKTO,3 IN (75M)HAWK	CRNG	00 95969 49608 7
ScopeMeters					
Industrial ScopeMeter					
Fluke 123	Industrial ScopeMeter (20 MHz)	2064239	FLUKE-123/001, INDUSTRI:SCM	SM12X	00 95969 05215 3
Fluke 123/S	Industrial ScopeMeter (20 MHz) + SCC120	2063903	FLUKE-123/001S, INDUST:SCM	SM12X	00 95969 05216 0
Fluke 124	Industrial ScopeMeter (40 MHz)	2064049	FLUKE-124/001, INDUSTRI:SCM	SM12X	00 95969 23435 1
Fluke 124/S	Industrial ScopeMeter (40 MHz) + SCC120	2064051	FLUKE-124/001S, INDUST:SCM	SM12X	00 95969 23436 8
Fluke 125	Industrial ScopeMeter (40 MHz) + Clamp i400s	2838888	FLUKE-125/001,40MHZ IN:SCM	SM12X	8 712031 02072 9
Fluke 125/S	Industrial ScopeMeter (40 MHz) + i400s + SCC120	2838973	FLUKE-125/001S,40MHZ I:SCM	SM12X	8 712031 02073 6
Fluke 123-179	Industrial Maintenance Department Kit	2071634	FLUKE 123-179 EFG, DEP:SCM	SM12X	00 95969 23733 8
190 Series ScopeMeters					
Fluke 192C	ScopeMeter (60 MHz/500 MS/s)	3379388	FLUKE-192C/001,SCOPEM:SCM	SM19X	8 712031 02152 8
Fluke 192C/S	ScopeMeter (60 MHz/500 MS/s) + SCC190	3379452	FLUKE-192C/001S,SCOPEM:SCM	SM19X	8 712031 02159 7
Fluke 196C	Color ScopeMeter (100 MHz/1 GS/s)	1634706	FLUKE-196C/001, SCOPEM:SCM	SM19X	00 95969 11289 5
Fluke 196C/S	Color ScopeMeter (100 MHz/1 GS/s) + SCC190	1634875	FLUKE-196C/001S, SCOPEI:SCM	SM19X	00 95969 11306 9
Fluke 199C	Color ScopeMeter (200 MHz/2.5 GS/s)	1635388	FLUKE-199C/001, SCOPEM:SCM	SM19X	00 95969 11357 1
Fluke 199C/S	Color ScopeMeter (200 MHz/2.5 GS/s) + SCC190	1635559	FLUKE-199C/001S, SCOPEI:SCM	SM19X	00 95969 11374 8
Fluke 215C	Color ScopeMeter (100 MHz/1 GS/s)	3379515	FLUKE-215C/001,SCOPEM:SCM	SM19X	8 712031 02165 8
Fluke 215C/S	Color ScopeMeter (100 MHz/1 GS/s) + SCC190	3379580	FLUKE-215C/001S,SCOPEM:SCM	SM19X	8 712031 02172 6
Fluke 225C	Color ScopeMeter (200 MHz/2.5 GS/s)	3379643	FLUKE-225C/001,SCOPEM:SCM	SM19X	8 712031 02178 8
Fluke 225C/S	Color ScopeMeter (200 MHz/2.5 GS/s) + SCC190	3379711	FLUKE-225C/001S,SCOPEM:SCM	SM19X	8 712031 02185 6
190 Series II ScopeMeters – 2CH + DMM					
Fluke 190-202/UN	ScopeMeter, 200 MHz, 2 channels plus DMM/Ext.input	4025472		SCM	SM29X
Fluke 190-202/UN/S	ScopeMeter, 200 MHz, 2 channels plus DMM/Ext.input, with SCC-290 kit	4025568		SCM	SM29X
Fluke 190-102/UN	ScopeMeter, 100 MHz, 2 channels plus DMM/Ext.input	4025329		SCM	SM29X
Fluke 190-102/UN/S	ScopeMeter, 100 MHz, 2 channels plus DMM/Ext.input, with SCC-290 kit	4025390		SCM	SM29X
Fluke 190-062/UN	ScopeMeter, 60 MHz, 2 channels plus DMM/Ext.input	4025171		SCM	SM29X
Fluke 190-062/UN/S	ScopeMeter, 60 MHz, 2 channels plus DMM/Ext.input, with SCC-290	4025248		SCM	SM29X
190 Series II ScopeMeters				SCM	SM29X

Typ	Fluke Industrial				
Fluke-190-204/EU	Scopemeter 4 Channel 200 MHz Color EU	3894409	FLUKE-190-204/EU,SCOPE SC	SM29X	8 712031 02254 9
Fluke-190-204/UN	Scopemeter 4 Channel 200 MHz Color UNI	3894411	FLUKE-190-204/UN,SCOPE SC	SM29X	8 712031 02255 6
Fluke-190-204/EU/S	Scopemeter 4 Channel 200 MHz Color EU SCC	3894475	FLUKE-190-204/EU/S,SCO SC	SM29X	8 712031 02259 4
Fluke-190-204/UN/S	Scopemeter 4 Channel 200 MHz Color UNI SCC	3894482	FLUKE-190-204/UN/S,SCO SC	SM29X	8 712031 02260 0
Fluke-190-104/EU	Scopemeter 4 Channel 100 MHz Color EU	3894540	FLUKE-190-104/EU,SCOPE SC	SM29X	8 712031 02244 0
Fluke-190-104/UN	Scopemeter 4 Channel 100 MHz Color UNI	3894557	FLUKE-190-104/UN,SCOPE SC	SM29X	8 712031 02245 7
Fluke-190-104/EU/S	Scopemeter 4 Channel 100 MHz Color EU SCC	3894617	FLUKE-190-104/EU/S,SCO SC	SM29X	8 712031 02249 5
Fluke-190-104/UN/S	Scopemeter 4 Channel 100 MHz Color UNI SCC	3894621	FLUKE-190-104/UN/S,SCO SC	SM29X	8 712031 02250 1
Medical ScopeMeters					
Fluke 196BM	ScopeMeter (100 MHz/1 GS/s), Medical version	2040270	FLUKE-196BM,SCOPEMETESCM	SM19X	00 95969 21650 0
Fluke 196CM	Color ScopeMeter (100 MHz/1 GS/s), Medical version	2040296	FLUKE-196CM,SCOPEMETESCM	SM19X	00 95969 21652 4
Fluke 199BM	ScopeMeter (200 MHz/2.5 GS/s), Medical version	2040281	FLUKE-199BM,SCOPEMETESCM	SM19X	00 95969 21651 7
Fluke 199CM	Color ScopeMeter (200 MHz/2.5 GS/s), Medical version	2040308	FLUKE-199CM,SCOPEMETESCM	SM19X	00 95969 21653 1
ScopeMeter Accessories					
AC120	Heavy Duty Alligator Clips	646163	AC120,ALLIGATOR CLIP-SISCM	12ACC	00 95969 05212 2
AS190-G	Probe Accessory Set, Grey	677377	AS190-G,PROBE ACCESSO SC	SMACC	00 95969 07569 5
AS190-R	Probe Accessory Set, Red	677382	AS190-R,PROBE ACCESSOISCM	SMACC	00 95969 07570 1
AS200-G	Probe Accessory Set, Grey	1586435	AS200-G,PROBE ACCESSO SC	SMACC	00 95969 09400 9
AS200-R	Probe Accessory Set, Red	1586420	AS200-R,PROBE ACCESSOISCM	SMACC	00 95969 09399 6
BB120	Banana to BNC Adapter Plug	646171	BB120,SET OF 2 BANANA SC	12ACC	00 95969 05213 9
BC190/801	Battery Charger/Line Voltage Adapter EUR (190 Series)	1282148	BC190/801,BATTERY CHAFSCM	SMACC	00 95969 07786 6
BC190/808	Battery Charger/Line Voltage Adapter UNIVERSAL (190 Series)	1282244	BC190/808,BATTERY CHAFSCM	SMACC	00 95969 07790 3
BHT190	Set of Break-out Adapters	3379374	BHT190,BUS HEALTH TES SC	SMACC	8 712031 02151 1
BP120MH	NiMH Battery Pack (120 Series/43B)	2544081	BP120MH,RECHARGEABLE SC	12ACC	00 95969 32723 7
BP130	NiMH Battery Pack (Fluke 124)	2040324	BP130,NIMH BATTERY PACSCM	SMACC	00 95969 21655 5
BP190	NiMH Battery Pack (190 Series)	677390	BP190,NIMH BATTERY PACSCM	SMACC	00 95969 07572 5
C120	Hard Case (43B/120 Series)	646189	C120,HARD CARRYING CASCM	12ACC	00 95969 05214 6
C125	Soft Meter Case	646858	C125,COMPACT SOFT CASSCM	12ACC	00 95969 05289 4
C190	Hard Case (190 Series)	677401	C190,HARDCASE SM 190 SSCM	SMACC	00 95969 07574 9
C195	Soft Case	677408	C195,SOFTCASE SC	SMACC	00 95969 07575 6
CS20MA	Current Shunt 4-20 mA	677393	CS20MA,CURRENT SHUNT SC	SMACC	00 95969 07573 2
DP120	Differential Probe	651759	DP120,DIFFERENTIAL PRCSCM	12ACC	00 95969 05606 9
HC120	Hook Clips	646668	HC120,SET OF 2 HOOK CLSCM	12ACC	00 95969 05263 4
HC200	Hook Clips	2086410	HC200,HOOK CLIP SET, 2 SC	SMACC	00 95969 24015 4
ITP120	Trigger Probe	646676	ITP120,ISOLATED TRIGGESCM	12ACC	00 95969 05264 1
MA190	Medical Accessory Kit (190 Series)	1567481	MA190,SCMTR MEDICAL ASCM	SMACC	00 95969 08740 7
OC4USB	Serial Interface Adapter/Cable (USB)	2166266	OC4USB,USB CABLE FOR SSCM	SMACC	00 95969 26543 0

Typ	Fluke Industrial				
PAC91	Printer Adapter Cable	614179	PAC91,PRINT ADAPTER C/SCM	SMACC	00 95969 04763 0
PM8907/801	Battery Charger/Line Voltage Adapter EUR (120 Series)	613999	PM8907/801,POWER ADAFSCM	SMACC	00 95969 04736 4
PM8907/808	Battery Charger/Line Voltage Adapter UNIVERSAL (120 Series)	614039	PM8907/808,POWER ADAFSCM	SMACC	00 95969 04738 8
PM8918/301	Low Pass Filter Probe	935101	PM8918/301,LOW PASS (4SCM	SMACC	00 95969 02235 4
PM9080	Serial Interface Adapter/Cable (RS232)	1641983	PM9080/101,OPTICAL TO SCM	SMACC	00 95969 11807 1
PM9081	Dual Banana Plug to Female BNC Adapter	916093	PM9081/001,DUAL BANAN.SCM	SMACC	00 95969 01492 2
PM9082	Dual Banana Jack to Male BNC Adapter	916163	PM9082/001,BANANA JACKSCM	SMACC	00 95969 01501 1
PM9090	Probe Pin Grabber Flexible Clip	916007	PM9090/001,SCOPEMETERSCM	SMACC	00 95969 01487 8
PM9091	Coaxial BNC Cables (1.5 m)	935598	PM9091/001,1.5M (5FT) S.SCM	SMACC	00 95969 02206 4
PM9092	Coaxial BNC Cables (0.5 m)	935601	PM9092/001,0.5M (1.5FT) SCM	SMACC	00 95969 02207 1
PM9093	Male BNC to Female BNC Adapter	935593	PM9093/001,SAFETY DESISCM	SMACC	00 95969 02205 7
PM9094/101	Mini Testhook Set for PM8918 Probes	610995	PM9094/101,MINI TESTHCSCM	SMACC	00 95969 04558 2
PM9096/201	Secondary Pick-up	651742	PM9096/201,SECONDARY SCM	98ACC	00 95969 05526 0
RS190	Probe Replacement Set	671823	RS190,PROBE REPLACEMESCM	SMACC	00 95969 07559 6
RS200	Probe Replacement Set	1586382	RS200,PROBE REPLACEMESCM	SMACC	00 95969 09398 9
SCC120E	FlukeView Software + USB Cable + Case (120 Series) - English	646684	SCC120E,SOFTWARE&CABSCM	12ACC	00 95969 05265 8
SCC128	Automotive Accessory Kit (120 Series)	2100199	SCC 128,AUTOMOTIVE ACSCM	SMACC	00 95969 24313 1
SCC198	Automotive Accessory Kit (190 Series)	2100208	SCC 198,AUTOMOTIVE ACSCM	SMACC	00 95969 24314 8
SCC190	FlukeView Software + Cable + Case (190 Series) - English, French, German	671826	SCC190EFG,SW & CABLE C/SCM	SMACC	00 95969 07560 2
STL90	Automotive Shielded Test Lead Set (120/190 Series)	201233	STL90,SHIELDED TESTLEASCM	98ACC	00 95969 04307 6
STL120	Shielded Test Lead Set	646718	STL120,SHIELDED TEST LISCM	12ACC	00 95969 05268 9
SW90W/034	FlukeView ScopeMeter Software (English, French, German)	1641990	SW90W/034EFG,FLUKEVIESCM	SMACC	00 95969 11808 8
TAS90	Automotive Accessory Set (120/190 Series)	614187	TAS90,SHIELDED TEST LE SCM	SMACC	00 95969 04764 7
VPS40	Voltage Probe (40 MHz, 10:1), Black	2040313	VPS40,VOLTAGE PROBE SISCM	SMACC	00 95969 21654 8
VPS100	Voltage Probe Set (100 MHz, 10:1)	1586464	VPS100,10:1 V. PROBE SE' SCM	SMACC	00 95969 09403 0
VPS100-R	Voltage Probe (100 MHz, 10:1), Red	1610638	VPS100-R,V.PROBE_RED,1SCM	SMACC	00 95969 10370 1
VPS101	1:1 Voltage Probe Set, black, 30 MHz, 1.2m	3086317	VPS101,1:1 VOLTAGE PROSCM	SMACC	00 95969 43585 7
VPS121	Voltage Probe Set (12 MHz, 1:1)	1586447	VPS121,1:1 V. PROBE BLA' SCM	SMACC	00 95969 09401 6
VPS200-G	Voltage Probe (200 MHz, 10:1), Grey	1586366	VPS200-G,10:1 V.PROBE GSCM	SMACC	00 95969 09397 2
VPS200-R	Voltage Probe (200 MHz, 10:1), Red	1586309	VPS200-R,10:1 V. PROBE FSCM	SMACC	00 95969 09396 5
VPS201	Voltage Probe Set (200 MHz, 100:1)	1586473	VPS201,100:1 V.PROBE SESCM	SMACC	00 95969 09404 7
VPS210-G	10:1 Voltage Probe Set, grey, 200 MHz, 1.2m	3086247	VPS210-G,10:1 VOLTAGE ISCM	SMACC	8 712031 02062 0
VPS210-R	10:1 Voltage Probe Set, 1 red, 200 MHz, 1.2m	3086235	VPS210-R,10:1 VOLTAGE FSCM	SMACC	8 712031 02061 3
VPS212-G	10:1 Voltage Probe Set, grey, 200 MHz, 2.5m	3086286	VPS212-G,10:1 VOLTAGE ISCM	SMACC	8 712031 02068 2
VPS212-R	10:1 Voltage Probe Set, red, 200 MHz, 2.5m	3086273	VPS212-R,10:1 VOLTAGE FSCM	SMACC	8 712031 02067 5
VPS220-G	100:1 Voltage Probe Set, grey, 200 MHz, 1.2m	3086300	VPS220-G,100:1 VOLTAGE SCM	SMACC	8 712031 02066 8
VPS220-R	100:1 Voltage Probe Set, red, 200 MHz, 1.2m	3086299	VPS220-R,100:1 VOLTAGE SCM	SMACC	8 712031 02065 1
VPS250	Voltage Probe Set (75 MHz, 10:1, 2,5 m)	1586458	VPS250,10:1 V.PROBE SETSCM	SMACC	00 95969 09402 3

Typ	Fluke Industrial				
ScopeMeter 190Series II Accessories					
BP290	2400 mAh Li-Ion Battery Pack for Fluke 190 Series II				
BP291	Li-Ion Battery Pack, Double Capacity, Fluke 190-SeriesII	3894688	BP291,LI-ION BATTERY PASC	SMACC	8 712031 02222 8
HH290	Hanging Hook				
EBC290	External Battery Charger				
VPS410-R	Voltage Probe Set 10:1, Red	3894707	VPS410-R,VOLTAGE PROBISCM	SMACC	8 712031 02230 3
VPS410-B	Voltage Probe Set 10:1, Blue	3894718	VPS410-B,VOLTAGE PROBISCM	SMACC	8 712031 02231 0
VPS410-G	Voltage Probe Set 10:1, Grey	3894729	VPS410-G,VOLTAGE PROB SC	SMACC	8 712031 02232 7
VPS410-V	Voltage Probe Set 10:1, Green	3894734	VPS410-V,VOLTAGE PROBISCM	SMACC	8 712031 02233 4
VPS420-R	High Working Voltage Probe, 100:1, Red&Black	3894783	C290,HARD-SHELL CARRY:SC	SMACC	8 712031 02226 6
C290	Hard-Shell Carrying Case	3894803	SCC290,SOFTWARE, CARRSC	SMACC	8 712031 02228 8
SCC290	Software And Carrying Case Kit	3894826			
RS400	Probe Accessory Replacement Set, For VPS400 Probes	3894867			
AS400	Probe Accessory Extension Set, For VPS400 Probes	3894880			
EBC290	External Batt.Charger, Li-Ion Batt.BP290-Series	3894906			
SW90W	Flukeview Scopemeter	3894923			
Power Quality Tools					
Fluke 43Basic	Power Quality Analyzer (single-phase)	2098866	FLUKE-43BASIC/001, POWFPQ	PQP	00 95969 24275 2
Fluke 43B	Power Quality Analyzer (single-phase)	1615428	FLUKE-43B/101,POWER QIFPQ	PQP	00 95969 10632 0
Fluke 345	Power Quality Clamp Meter	2584181	FLUKE-345,POWER QUALI FPQ	PQP	00 95969 34499 9
Fluke 433/UGK	Upgrade Kit for Fluke 433	2277107	FLUKE-433/UGK,UPGRADE FPQ	PQ43X	00 95969 26854 7
Fluke 434/Basic	Power Quality Analyzer (three-phase)	2806307	FLUKE-434/BASIC,POWER FPQ	PQ43X	00 95969 39429 1
Fluke 434	Power Quality Analyzer (three-phase)	2162296	FLUKE-434/001,POWER QIFPQ	PQ43X	00 95969 26404 4
Fluke 434/LOG	Upgrade kit for Fluke 434	2654876	FLUKE-434/LOG, FIRMWAF PQ	PQ43X	00 95969 35303 8
Fluke 435/Basic	Power Quality Analyzer (three-phase)	2806318	FLUKE-435/BASIC,POWER FPQ	PQ43X	00 95969 39430 7
Fluke 435	Power Quality Analyzer (three-phase)	2654779	FLUKE-435/001,POWER QIFPQ	PQ43X	00 95969 35295 6
Fluke 434-II	Three-Phase Energy Analyzer	4116638			
Fluke 434-II/Basic	Three-Phase Energy Analyzer Basic	4116650			
Fluke 435-II	Three-Phase Power Quality and Energy Analyzer	4116661			
Fluke 435-II/Basic	Three-Phase Power Quality and Energy Analyzer Basic	4116689			
Fluke 437-II	Three-Phase Power Quality and Energy Analyzer 400Hz	4116692			
Fluke 437-II/Basic	Three-Phase Power Quality and Energy Analyzer 400Hz Basic	4116719			
Fluke 1735	Power Logger (three-phase)	2583398	FLUKE-1735,POWER LOGGFPQ	PQ173	00 95969 34472 2
Fluke 1743 Basic	Power Quality Logger, Memobox	3034012	FLUKE-1743 BASIC,POWEFFPQ	PQ174	00 95969 41700 6
Fluke 1743	Power Quality Logger, Memobox	2583446	FLUKE-1743,POWER QUALFPQ	PQ174	00 95969 34476 0
Fluke 1744 Basic	Power Quality Logger, Memobox	3034020	FLUKE-1744 BASIC,POWEFFPQ	PQ174	00 95969 41701 3

Typ	Fluke Industrial				
Fluke 1744/1PH	Power Quality Logger, Memobox, 1 phase	3345730	FLUKE-1744/1PH,POWER (FPQ	PQ174	00 95969 47171 8
Fluke 1744	Power Quality Logger, Memobox	2583422	FLUKE-1744,POWER QUALFPQ	PQ174	00 95969 34474 6
Fluke 1745	Power Quality Logger, Memobox	2583468	FLUKE-1745,POWER QUALFPQ	PQ174	00 95969 34478 4
Fluke 1760 Basic	Power Quality Recorder (three-phase), Topas	2630732	FLUKE-1760 BASIC,POWEFFPQ	PQ176	00 95969 34609 2
Fluke 1760	Power Quality Recorder (three-phase), Topas	2630744	FLUKE-1760 INTL,POWER FPQ	PQ176	00 95969 34610 8
Fluke 1760TR Basic	Power Quality Recorder (three-phase), Topas	2637629	FLUKE-1760TR BASIC,POWFPQ	PQ176	00 95969 34823 2
Fluke 1760TR	Power Quality Recorder (three-phase), Topas	2637634	FLUKE-1760 TR INTL,POWFPQ	PQ176	00 95969 34824 9
Fluke 1750	Three-Phase Power Recorder	2157153			
Fluke 1750/B	Three-Phase Power Recorder – Basic	3107226			
Fluke VR1710	Single-Phase Voltage Quality Recorder	3030923	FLUKE-VR1710,VOLTAGE (FPQ	PQVR1	00 95969 41655 9
Power Quality Tools Accessories					
3110-PR	100 Amp Flexi-CT, 2 - 100 amps flexible current transformer, 24" long.	3036740	100 Amp Flexi-CT, 2 - 100 amps flexible current transformer, 24" long.		
3210-PR	1000 Amp Flexi-CT, 20 - 1000 amps flexible current transformer, 24" long.	3036778	1000 Amp Flexi-CT, 20 - 1000 amps flexible current transformer, 24" long.		
3310-PR	5000 Amp Flexi-CT, 100 - 5000 amps flexible current transformer, 24" long.	3036791	5000 Amp Flexi-CT, 100 - 5000 amps flexible current transformer, 24" long.		
3312-PR	5000 Amp Flexi-CT, 100 - 5000 amps flexible current transformer, 48" long.	3036804	5000 Amp Flexi-CT, 100 - 5000 amps flexible current transformer, 48" long.		
3005-PR	0.1 - 5 amps clamp-on current transformer with 10' Extender cable for P	3061628	0.1 - 5 amps clamp-on current transformer with 10' Extender cable for P		
3014-PR	0.1 - 40 amps clamp-on current transformer with 10' Extender cable for I	3036936	0.1 - 40 amps clamp-on current transformer with 10' Extender cable for I		
3140R	2 - 400 amps clamp-on current transformer with 8' cable for Power Reco	2650136	2 - 400 amps clamp-on current transformer with 8' cable for Power Reco		
FLUKE-1750/SEAT-L	One additional license for installation on one additional PC	2673937	One additional license for installation on one additional PC		
FLUKE-1750/SITE-L	Site license for installation on unlimited PCs	2673928	Site license for installation on unlimited PCs		
FLUKE-1750/CASE	Transit Case - Water-tight hard case with rollers for Fluke 1750 and Fluke	2650124	Transit Case - Water-tight hard case with rollers for Fluke 1750 and Fluke		
CS1750	Carry Bag for 1750; Rugged, canvas bag for monitor with pockets for acc	2673962	Carry Bag for 1750; Rugged, canvas bag for monitor with pockets for acc		
HP IPAQ 2490	Additional Wireless Interface PDA for Fluke 1750	2586088	Additional Wireless Interface PDA for Fluke 1750		
FLUKE-1750/MC	Additional 512Mb SD Memory Card for Fluke 1750	2586074	Additional 512Mb SD Memory Card for Fluke 1750		
1750/CASE	Hard Case (Fluke 1750)	2650124	FLUKE-1750/CASE, TRANSFPQ	RPMAC	00 95969 35137 9
BC430	Battery Charger/Line Voltage Adapter	2277129	BC430,BATTERY CHARGERFPQ	PQ43X	00 95969 26856 1
BC1735	Battery Charger	2584895	BC1735,BATTERY CHARGEFPQ	PQ174	00 95969 34506 4
BE345	Battery Eliminator (Fluke 345)	2839604	BE345,UNIVERSAL BATTERFPQ	PQP	00 95969 40111 1
BP120MH	NiMH Battery Pack (120 Series/43B)	2544081	BP120MH,RECHARGEABLE SCM	12ACC	00 95969 32723 7
CF1760-2GB	Compact Flash Card 2GB (Fluke 1760)	2726620	CF1760-2GB,X7698020000FPQ	LPORT	00 95969 36455 3
C120	Hard Case (43B/120 Series)	646189	C120,HARD CARRYING CA:SCM	12ACC	00 95969 05214 6
C430	Hard Case (430 Series)	2277134	C430,HARD CARRYING CA:FPQ	PQ43X	00 95969 26857 8
C435	Hard Case with rollers (430 Series)	2654865	C435,WATER-TIGHT HARDFPQ	PQ43X	00 95969 35302 1
CS1760	Crossover Ethernet Cable (Fluke 1760)	2726601	CS1760,X57320800100,CRFPQ	PQ176	00 95969 36453 9
FS17XX	4-Phase Flex Current Clamp Set (1735/1743)	2637462	FS17XX,SHIELDED 4-PHASEFPQ	LOGGR	00 95969 34820 1

Typ	Fluke Industrial				
GPS430	GPS Time Synchronization Module (430 Series)	2654841	GPS430,GPS SYNC MODULFPQ	PQ43X	00 95969 35300 7
GPS-TIME SYNC	GPS Time Synchronization Module (Fluke 1760)	2539223	GPS-TIME SYNC,EP2050Z, FPQ	LINST	00 95969 32447 2
i1A/10A CLAMP PQ1	I1A/10A CLAMP PQ1,1-PHASE 1A/10A MINI CURRENT CLAMP SET FOR F3345753	3024413	I1A/10A CLAMP PQ1,1-PH/FPQ	LOGGR	00 95969 47173 2
i1A/10A CLAMP PQ3	3-phase Mini Current Clamp Set	3024413	I1A/10A CLAMP PQ3,3-PH/FPQ	LOGGR	00 95969 41396 1
i1A/10A CLAMP PQ4	4-phase Mini Current Clamp Set	3024424	I1A/10A CLAMP PQ4,4-PH/FPQ	LOGGR	00 95969 41397 8
i5A/50A CLAMP PQ3	3-phase Mini Current Clamp Set	3024436	I5A/50A CLAMP PQ3,3-PH/FPQ	LOGGR	00 95969 41398 5
i5A/50A CLAMP PQ4	4-phase Mini Current Clamp Set	3024449	I5A/50A CLAMP PQ4,4-PH/FPQ	LOGGR	00 95969 41399 2
i5s	AC Current Clamp (5 A)	2508467	I5S,5A AC CURRENT PROBACC	PRCU	00 95969 30865 6
i5sPQ3	AC Current Clamp (5 A), 3-pack	2457508	I5SPQ3,5A AC CURRENT PACC	PRCU	00 95969 29381 5
i20/200A CLAMP PQ3	3-phase Mini Current Clamp Set	3024451	I20/200A CLAMP PQ3,3-PH/FPQ	LOGGR	00 95969 41400 5
i20/200A CLAMP PQ4	4-phase Mini Current Clamp Set	3024460	I20/200A CLAMP PQ4,4-PH/FPQ	LOGGR	00 95969 41401 2
i400s	AC Current Clamp (400A)	2277202	I400S,AC CURRENT CLAMFACC	PRCU	00 95969 26858 5
i430-flex	AC Flexible Current Clamp 3000A (430 Series)	2654883	I430-FLEX, AC FLEX CURRIACC	PRCU	00 95969 35304 5
i430-flex-4pk	AC Flex Current Clamp 3000A, 4-pack (430 Series)	2654852	I430-FLEX-4PK, AC FLEX CACC	PRCU	00 95969 35301 4
OC4USB	Serial Interface Adapter/Cable (USB)	2166266	OC4USB,USB CABLE FOR SSCM	SMACC	00 95969 26543 0
PM9080	Serial Interface Adapter/Cable (RS232)	1641983	PM9080/101,OPTICAL TO SCM	SMACC	00 95969 11807 1
ST1760	Standard Ethernet Cable	2726612	ST1760,X57320810100,ST.FPQ	LPORT	00 95969 36454 6
SW43W	FlukeView Software (Fluke 43B/430 Series)	2098918	SW43W,FLUKEVIEW 43 SCFPQ	PQP	00 95969 24280 6
TLS430	Test Leads and Alligator Clips (4 black, 1 green) - 430 Series	2157713	TLS430,TEST LEAD SET 4:ACC	KITS	00 95969 26298 9
TPS CLAMP 10A/1A	Clip-on Current Transformer 10A/1A (Fluke 1760)	2540445	TPS CLAMP 10A/1A,A6805FPQ	LINST	00 95969 32569 1
TPS CLAMP 50A/5A	Clip-on Current Transformer 50A/5A (Fluke 1760)	2540461	TPS CLAMP 50A/5A,A6805FPQ	LINST	00 95969 32571 4
TPS CLAMP 200A/20A	Clip-on Current Transformer 200A/20A (Fluke 1760)	2540450	TPS CLAMP 200/20,A6805FPQ	LINST	00 95969 32570 7
TPS FLEX 18	Flexible Current Probe 500A (Fluke 1760)	2540477	TPS FLEX 18,EP1205A, CUIFPQ	LINST	00 95969 32572 1
TPS FLEX 24	Flexible Current Probe 1000A (Fluke 1760)	2540489	TPS FLEX 24,EP1210A, CUIFPQ	LINST	00 95969 32573 8
TPS FLEX 36	Flexible Current Probe 6000A (Fluke 1760)	2540492	TPS FLEX 36,EP1360A, CUIFPQ	LINST	00 95969 32574 5
TPS SHUNT 20MA	Shunt 20mA AC/DC (Fluke 1760)	2540553	TPS SHUNT 20MA,A68050:FPQ	LINST	00 95969 32580 6
TPS VOLTPROBE 10V	Voltage Probe 10V (Fluke 1760)	2540636	TPS VOLTPROBE 10V,EP2CFPQ	LINST	00 95969 32588 2
TPS VOLTPROBE 100V	Voltage Probe 100V (Fluke 1760)	2540624	TPS VOLTPROBE 100V,EP2FPQ	LINST	00 95969 32587 5
TPS VOLTPROBE 400V	Voltage Probe 400V (Fluke 1760)	2540660	TPS VOLTPROBE 400V,EP2FPQ	LINST	00 95969 32591 2
TPS VOLTPROBE 600V	Voltage Probe 600V (Fluke 1760)	2540697	TPS VOLTPROBE 600V,EP2FPQ	LINST	00 95969 32594 3
TPS VOLTPROBE 1KV	Voltage Probe 1000V (Fluke 1760)	2540649	TPS VOLTPROBE 1K V,EP2FPQ	LINST	00 95969 32589 9
VPS40	Voltage Probe (40 MHz, 10:1), Black	2040313	VPS40,VOLTAGE PROBE SISCM	SMACC	00 95969 21654 8
WC100	Color Localization Set (430 Series)	2157607	WC100,MULTI COLOR WIFACC	LEAD	00 95969 27153 0
i430-Flexi-TF	Fluke 430 Thin Flexi 6000A 61cm (24in)	3889434			
i430-Flexi-TF 4pk	Fluke 430 Thin Flexi 6000A 61cm (24in) – 4 pack	3889441			
C437-II	Hard Case 430 Series II with Rollers	4116743			
C1740	Softcase for 174X and 43X-II PQ Analyzer	4116762			

Typ	Fluke Industrial				
1743/1744 POLESET	Pole Mounting Kit (Fluke 1743/1744)	3024485	1743/44 POLESET,POLE MFPQ	LOGGR	00 95969 41403 6
Power Analyzers					
Norma 4000					
Fluke N4K 1PP42	1 PH N4k power analyzer w/42	3108534	FLUKE-N4K 1PP42,1 PH N4FPQ	NORMA	00 95969 44055 4
Fluke N4K 3PP42	3 PH N4k power analyzer w/42	3108541	FLUKE-N4K 3PP42,3 PH N4FPQ	NORMA	00 95969 44056 1
Fluke N4K 3PP42I	3 PH N4k power analyzer w/42/IFC2	3108552	FLUKE-N4K 3PP42I,3 PH NFPQ	NORMA	00 95969 44057 8
Fluke N4K 3PP42IP	3 PH N4k power analyzer w/42/IFC2 & PI1	3108565	FLUKE-N4K 3PP42IP,3 PH IFPQ	NORMA	00 95969 44058 5
Fluke N4K 3PP50	3 PH N4k power analyzer w/50	3108576	FLUKE-N4K 3PP50,3 PH N4FPQ	NORMA	00 95969 44059 2
Fluke N4K 3PP50I	3 PH N4k power analyzer w/50/IFC2	3108583	FLUKE-N4K 3PP50I,3 PH NFPQ	NORMA	00 95969 44060 8
Fluke N4K 3PP50IP	3 PH N4k power analyzer w/50/IFC2 & PI1	3108590	FLUKE-N4K 3PP50IP,3 PH IFPQ	NORMA	00 95969 44061 5
Fluke N4K 3PP54I	3 PH N4k power analyzer w/54/IFC2	3108601	FLUKE-N4K 3PP54I,3 PH NFPQ	NORMA	00 95969 44062 2
Fluke N4K 3PP54IP	3 PH N4k power analyzer w/54/IFC2 & PI1	3108612	FLUKE-N4K 3PP54IP,3 PH IFPQ	NORMA	00 95969 44063 9
Fluke N4K 3PP42B	3 PH N4k power analyzer w/42BP	3110957	FLUKE-N4K 3PP42B,3 PH NFPQ	NORMA	00 95969 44147 6
Fluke N4K 3PP42IB	3 PH N4k power analyzer w/42BP/IFC2	3110969	FLUKE-N4K 3PP42IB,3 PH FPQ	NORMA	00 95969 44148 3
Fluke N4K 3PP42IPB	3 PH N4k power analyzer w/42BP/IFC2 & PI1	3110978	FLUKE-N4K 3PP42IPB,3 PH IFPQ	NORMA	00 95969 44149 0
Fluke N4K 3PP52IB	3 PH N4k power analyzer w/52BP/IFC2	3312894	FLUKE-N4K 3PP52IB,3 PH FPQ	NORMA	00 95969 46393 5
Norma 5000					
Fluke N5K 3PP50	3 PH N5k power analyzer w/50	3108620	FLUKE-N5K 3PP50,3 PH N5FPQ	NORMA	00 95969 44064 6
Fluke N5K 3PP50I	3 PH N5k power analyzer w/50/IFC2	3108635	FLUKE-N5K 3PP50I,3 PH NFPQ	NORMA	00 95969 44065 3
Fluke N5K 3PP50IP	3 PH N5k power analyzer w/50/IFC2 & PI1	3108647	FLUKE-N5K 3PP50IP,3 PH IFPQ	NORMA	00 95969 44066 0
Fluke N5K 3PP54	3 PH N5k power analyzer w/54	3108658	FLUKE-N5K 3PP54,3 PH N5FPQ	NORMA	00 95969 44067 7
Fluke N5K 3PP54I	3 PH N5k power analyzer w/54/IFC2	3108664	FLUKE-N5K 3PP54I,3 PH NFPQ	NORMA	00 95969 44068 4
Fluke N5K 3PP54IP	3 PH N5k power analyzer w/54/IFC2 & PI1	3108673	FLUKE-N5K 3PP54IP,3 PH IFPQ	NORMA	00 95969 44069 1
Fluke N5K 3PP64	3 PH N5k power analyzer w/64	3108686	FLUKE-N5K 3PP64,3 PH N5FPQ	NORMA	00 95969 44070 7
Fluke N5K 3PP64I	3 PH N5k power analyzer w/64/IFC2	3108699	FLUKE-N5K 3PP64I,3 PH NFPQ	NORMA	00 95969 44071 4
Fluke N5K 3PP64IP	3 PH N5k power analyzer w/64/IFC2 & PI1	3108702	FLUKE-N5K 3PP64IP,3 PH IFPQ	NORMA	00 95969 44072 1
Fluke N5K 3PP54R	3 PH N5K power analyzer w/54/printer	3312934	FLUKE-N5K 3PP54R,3 PH NFPQ	NORMA	00 95969 46397 3
Fluke N5K 3PP54IR	3 PH N5K power analyzer w/54/IFC2/printer	3312941	FLUKE-N5K 3PP54IR,3 PH FPQ	NORMA	00 95969 46398 0
Fluke N5K 3PP64R	3 PH N5K power analyzer w/64/printer	3312952	FLUKE-N5K 3PP64R,3 PH NFPQ	NORMA	00 95969 46399 7
Fluke N5K 3PP64IR	3 PH N5K power analyzer w/64/IFC2/printer	3312965	FLUKE-N5K 3PP64IR,3 PH FPQ	NORMA	00 95969 46400 0
Fluke N5K 3PP64IPR	3 PH N5K power analyzer w/64/IFC2 & PI1/printer	3312976	FLUKE-N5K 3PP64IPR,3 PH IFPQ	NORMA	00 95969 46401 7
Fluke N5K 4PP54	4 PH N5k power analyzer w/54	3108716	FLUKE-N5K 4PP54,4 PH N5FPQ	NORMA	00 95969 44073 8
Fluke N5K 4PP54IP	4 PH N5k power analyzer w/54/IFC2 & PI1	3108725	FLUKE-N5K 4PP54IP,4 PH IFPQ	NORMA	00 95969 44074 5
Fluke N5K 6PP54I	6 PH N5k power analyzer w/50/IFC2	3108733	FLUKE-N5K 6PP54I,6 PH NFPQ	NORMA	00 95969 44075 2
Fluke N5K 6PP54IP	6 PH N5k power analyzer w/50/IFC2 & PI1	3108740	FLUKE-N5K 6PP54IP,6 PH IFPQ	NORMA	00 95969 44076 9

Typ	Fluke Industrial				
Fluke N5K 6PP64I	6 PH N5k power analyzer w/64/IFC2	3108757	FLUKE-N5K 6PP64I,6 PH NFPQ	NORMA	00 95969 44077 6
Fluke N5K 6PP64IP	6 PH N5k power analyzer w/64/IFC2 & PI1	3108769	FLUKE-N5K 6PP64IP,6 PH IFPQ	NORMA	00 95969 44078 3
Fluke N5K 6PP50I	6 PH N5k power analyzer w/50/IFC2	3312907	FLUKE-N5K 6PP50I,6 PH NFPQ	NORMA	00 95969 46394 2
Fluke N5K 6PP50IP	6 PH N5K power analyzer w/50/IFC2 & PI1	3312918	FLUKE-N5K 6PP50IP,6 PH IFPQ	NORMA	00 95969 46395 9
Fluke N5K 6PP42IB	6 PH N5K power analyzer w/42BP/IFC2	3312929	FLUKE-N5K 6PP42IB,6 PH FPQ	NORMA	00 95969 46396 6
Fluke N5K 6PP54IR	6 PH N5K power analyzer w/54/IFC2/printer	3312983	FLUKE-N5K 6PP54IR,6 PH FPQ	NORMA	00 95969 46402 4
Fluke N5K 6PP54IPR	6 PH N5K power analyzer w/54/IFC2 & PI1/printer	3312990	FLUKE-N5K 6PP54IPR,6 PH FPQ	NORMA	00 95969 46403 1
Fluke N5K 6PP50IR	6 PH N5K power analyzers w/50/IFC2/printer	3313003	FLUKE-N5K 6PP50IR,6 PH FPQ	NORMA	00 95969 46404 8
Fluke N5K 6PP50IPR	6 PH N5K power analyzers W/50/IFC2 & PI1/printer	3313015	FLUKE-N5K 6PP50IPR,6 PH FPQ	NORMA	00 95969 46405 5
Fluke N5K 6PP64IR	6 PH N5K power analyzer w/64/IFC2/printer	3313026	FLUKE-N5K 6PP64IR,6 PH FPQ	NORMA	00 95969 46406 2
Fluke N5K 6PP64IPR	6 PH N5K power analyzer w/64/IFC2 & PI1/Printer	3313032	FLUKE-N5K 6PP64IPR,6 PH FPQ	NORMA	00 95969 46407 9
Fluke N5K 6PP42IBR	6 PH N5K power analyzer W/42BP/IFC2/printer	3313044	FLUKE-N5K 6PP42IBR,6 PH FPQ	NORMA	00 95969 46408 6
Norma 4000/5000 Accessories			NORMA 10A SHUNT,TRIAFPQ	LPOM	00 95969 41443 2
Norma 10A shunt	Traxial Shunt	3024886	NORMA 30A SHUNT,TRIAFPQ	LPOM	00 95969 41444 9
Norma 30A shunt	Traxial Shunt	3024899	NORMA 32A SHUNT,32A PFPQ	LPOM	00 95969 41422 7
Norma 32A shunt	32A planar shunt	3024677	NORMA 32A CABLES,CABLFPQ	LPOM	00 95969 41423 4
Norma 32A cables	Cables for 32A planar shunt	3024689	NORMA 100A SHUNT,EXTEFPQ	LPOM	00 95969 41439 5
Norma 100A shunt	100 A Shunt with Cables (0.001 Ohm, 0 to 0.5 MHz)	3024847	NORMA 150A SHUNT,EXTEFPQ	LPOM	00 95969 41440 1
Norma 150A shunt	150 A Shunt with Cables (0.5 mOhm, 0 to 0.5 MHz)	3024858	NORMA 300A SHUNT,EXTEFPQ	LPOM	00 95969 41441 8
Norma 300A shunt	300 A Shunt with Cables (0.1 mOhm, 0 to 1 MHz)	3024864	NORMA 500A SHUNT,EXTEFPQ	LPOM	00 95969 41442 5
Norma 500A shunt	500 A Shunt with Cables (0.1 mOhm, 0 to 0.2 MHz)	3024873	NORMA LG SHUNT/CBL,CAFPQ	LPOM	00 95969 41424 1
Norma Lg shunt/cbl	LG Shunt Cables for High Current Shunts	3024692	NORMA MEAS CABLES,ME/FPQ	LPOM	00 95969 41421 0
Norma meas cables	Measurement cable set for one power phase 1.5m	3024661	NORMA STAR POINT,EXTEFPQ	LPOM	00 95969 41425 8
Norma wye adapter	External accessory box	3024704	FLUKE-N4K RACK KIT,N4K FPQ	NORMA	00 95969 46409 3
Fluke N4K RACK KIT	N4K 19 inch rack mount kit with handles	3313059	FLUKE-N5K RACK KIT,N5K FPQ	NORMA	00 95969 46410 9
Fluke N5K RACK KIT	N5K 19 inch rack mount kit with handles	3313067	NORMA 10A SHUNT,TRIAFPQ	LPOM	00 95969 41443 2
Vibration Testers					
Fluke 810	Vibration Tester	3542635	FLUKE-810	FLUKE-810MECH	FL8XX
810S	Sensor	3530828	810S	810S,SENMECH	FL8XX
810T	Tachometer	3530819	810T	810T,TACHMECH	FL8XX
810QDC	Quick Disconnect Cable	3530837	810QDC	810QDC,QMECH	FL8XX
810SMM	Sensor Magnet Mount	3530862	810SMM	810SMM,SMECH	FL8XX
810SMP	Sensor Mounting Pads (10-pack)	3530855	810SMP	810SMP,SIMECH	FL8XX
SBP-810	Smart Battery Pack	3530843	SBP810	SBP810,SMMECH	FL8XX
Process Calibrators					

Typ	Fluke Industrial				
700 Series Process Calibrators					
Fluke 705	Loop Calibrator	665091	FLUKE-705,LOOP CALIBRAPTOOL	F70X	00 95969 06256 5
Fluke 707	Loop Calibrator	1617262	FLUKE-707,LOOP CALIBRAPTOOL	F70X	00 95969 10715 0
Fluke 707Ex	Intrinsically Safe Loop Calibrator	2032187	FLUKE-707EX,MA CALIBRAPTOOL	F70X	00 95969 20728 7
Fluke 712	RTD Calibrator	620069	FLUKE-712,RTD CALIBRAPTOOL	F71X	00 95969 05065 4
Fluke 714	Thermocouple Calibrator	620093	FLUKE-714,THERMOCOUPITPTOOL	F71X	00 95969 05068 5
Fluke 715	Volt/mA Calibrator	620101	FLUKE-715,VOLT/MA CALIPTOOL	F71X	00 95969 05069 2
Fluke 717 1G	Pressure Calibrator (68.9 mbar)	2547166	FLUKE-717 1G,PRESSURE IPTOOL	F71X	00 95969 32766 4
Fluke 717 30G	Pressure Calibrator (2 bar)	662897	FLUKE-717 30G,PRESSUREPTOOL	F71X	00 95969 05989 3
Fluke 717 100G	Pressure Calibrator (7 bar)	1630430	FLUKE-717 100G,PRESSURPTOOL	F71X	00 95969 11107 2
Fluke 717 300G	Pressure Calibrator (20 bar)	2547175	FLUKE-717 300G,PRESSURPTOOL	F71X	00 95969 32767 1
Fluke 717 500G	Pressure Calibrator (34.7 bar)	2547182	FLUKE-717 500G,PRESSURPTOOL	F71X	00 95969 32768 8
Fluke 717 1000G	Pressure Calibrator (69 bar)	2547194	FLUKE-717 1000G,PRESSUPTOOL	F71X	00 95969 32769 5
Fluke 717 1500G	Pressure Calibrator (103.4 bar)	2547203	FLUKE-717 1500G,PRESSUPTOOL	F71X	00 95969 32770 1
Fluke 717 3000G	Pressure Calibrator (207 bar)	2547215	FLUKE-717 3000G,PRESSUPTOOL	F71X	00 95969 32771 8
Fluke 717 5000G	Pressure Calibrator (345 bar)	2547232	FLUKE-717 5000G,PRESSUPTOOL	F71X	00 95969 32773 2
Fluke 718 1G	Pressure Calibrator (68.9 mbar)	2547148	FLUKE-718 1G,PRESSURE IPTOOL	F71X	00 95969 32764 0
Fluke 718 30G	Pressure Calibrator (2 bar)	665075	FLUKE-718 30US,PRESSURPTOOL	F71X	00 95969 06208 4
Fluke 718 100G	Pressure Calibrator (7 bar)	665080	FLUKE-718 100US,PRESSUPTOOL	F71X	00 95969 06209 1
Fluke 718 300G	Pressure Calibrator (20 bar)	2547153	FLUKE-718 300G,PRESSURPTOOL	F71X	00 95969 32765 7
Fluke 718Ex 30G	Intrinsically Safe Pressure Calibrator (2 bar)	2096310	FLUKE-718EX 30,I.S. PRESPTOOL	F71X	00 95969 24164 9
Fluke 718Ex 100G	Intrinsically Safe Pressure Calibrator (7 bar)	2096322	FLUKE-718EX 100,I.S. PREPTOOL	F71X	00 95969 24165 6
Fluke 718Ex 300G	Intrinsically Safe Pressure Calibrator (20 bar)	3023328	FLUKE-718EX 300,I.S. PREPTOOL	F71X	00 95969 41386 2
Fluke 719 30G	Electric Pressure Calibrator, 30PSI, 2 bar	3315332	FLUKE-719 30G,ELECTRIC PTOOL	F71X	00 95969 46536 6
Fluke 719 100G	Electric Pressure Calibrator, 100PSI, 7 bar	3315344	FLUKE-719 100G, ELECTRIPTOOL	F71X	00 95969 46537 3
Fluke 724	Temperature Calibrator	1553041	FLUKE-724,TEMPERATUREPTOOL	F72X	00 95969 08335 5
Fluke 725	Multifunction Process Calibrator	664133	FLUKE-725 US,MULTIFUNCPTOOL	F72X	00 95969 06350 0
Fluke 725Ex	Intrinsically Safe Multifunction Process Calibrator	2098179	FLUKE-725EX,I.S. MULTIFIPTOOL	F72X	00 95969 24237 0
Fluke 726	Precision Multifunction Process Calibrator	2452080	FLUKE-726,PRECISION MUPTOOL	F72X	00 95969 29327 3
Fluke 741B	Documenting Process Calibrator	646976	FLUKE-741B INTL,DOCUMIPTOOL	F74X	00 95969 05328 0
Fluke 743B	Documenting Process Calibrator	646981	FLUKE-743B INTL,DOCUMIPTOOL	F74X	00 95969 05329 7
Fluke 744	Documenting Process Calibrator	662764	FLUKE-744 INTL,DOCUMIPTOOL	F74X	00 95969 05904 6
Fluke 771	Milliamp Process Clamp Meter	2646347	FLUKE-771,MILLIAMP PROPTOOL	F77X	00 95969 34969 7
Fluke 772	Milliamp Process Clamp Meter with mA source	3362352	FLUKE-772, MILLIAMP PRCPTOOL	F77X	00 95969 47581 5
Fluke 773	Milliamp Process Clamp Meter with mA and V source	3362365	FLUKE-773, MILLIAMP PRCPTOOL	F77X	00 95969 47582 2
Fluke 787	ProcessMeter	619913	FLUKE-787,PROCESSMETEPTOOL	F78X	00 95969 04832 3
Fluke 789	ProcessMeter	1633984	FLUKE-789,PROCESSMETEPTOOL	F78X	00 95969 11219 2
Pressure Modules			FLUKE-700P00,PRESSURE PTOOL	F700P	00 95969 07087 4

Typ	Fluke Industrial				
700P00	Differential Pressure Module (2.5 mbar)	667391	FLUKE-700P01,PRESSURE PTOOL	F700P	00 95969 02211 8
700P01	Differential Pressure Module (25 mbar)	936005	FLUKE-700P01EX,I.S. PRE\$PTOOL	F700P	00 95969 24193 9
700P01Ex	Differential Pressure Module (25 mbar)	2097578	FLUKE-700P02,PRESSURE PTOOL	F700P	00 95969 02212 5
700P02	Differential Pressure Module (70 mbar)	936013	FLUKE-700P22,PRESSURE PTOOL	F700P	00 95969 04287 1
700P22	Differential Pressure Module Wet (70 mbar)	100138	FLUKE-700P03,PRESSURE PTOOL	F700P	00 95969 02213 2
700P03	Differential Pressure Module (340 mbar)	936018	FLUKE-700P23,PRESSURE PTOOL	F700P	00 95969 04288 8
700P23	Differential Pressure Module Wet (340 mbar)	100146	FLUKE-700P04,PRESSURE PTOOL	F700P	00 95969 02214 9
700P04	Differential Pressure Module (1000 mbar)	936021	FLUKE-700P24,PRESSURE PTOOL	F700P	00 95969 04289 5
700P24	Differential Pressure Module Wet (1000 mbar)	100153	FLUKE-700P00,PRESSURE PTOOL	F700P	00 95969 07087 4
700P24Ex	Differential Pressure Module Wet (1001 mbar)	2097584	FLUKE-700P24EX,I.S. PRE\$PTOOL	F700P	00 95969 24194 6
700P05	Gage Pressure Module (2 bar)	936026	FLUKE-700P05,PRESSURE PTOOL	F700P	00 95969 02215 6
700P05Ex	Gage Pressure Module (2 bar)	2097591	FLUKE-700P05EX, I.S. PREPTOOL	F700P	00 95969 24195 3
700P06	Gage Pressure Module (7 bar)	936034	FLUKE-700P06,PRESSURE PTOOL	F700P	00 95969 02216 3
700P06Ex	Gage Pressure Module (7 bar)	2097600	FLUKE-700P06EX, I.S. PREPTOOL	F700P	00 95969 24196 0
700P27	Gage Pressure Module (20 bar)	1549399	FLUKE-700P27,PRESSURE PTOOL	F700P	00 95969 08319 5
700P27Ex	Gage Pressure Module (20 bar)	2097639	FLUKE-700P27EX,I.S. PRE\$PTOOL	F700P	00 95969 24199 1
700P07	Gage Pressure Module (34 bar)	936039	FLUKE-700P07,PRESSURE PTOOL	F700P	00 95969 02217 0
700P08	Gage Pressure Module (70 bar)	936042	FLUKE-700P08,PRESSURE PTOOL	F700P	00 95969 02218 7
700P09	Gage Pressure Module (100 bar)	617123	FLUKE-700P09,PRESSURE PTOOL	F700P	00 95969 04791 3
700P09Ex	Gage Pressure Module (100 bar)	2097617	FLUKE-700P09EX, I.S. PREPTOOL	F700P	00 95969 24197 7
700P29	Gage Pressure Module (200 bar)	612157	FLUKE-700P29,PRESSURE PTOOL	F700P	00 95969 04577 3
700P29Ex	Gage Pressure Module (200 bar)	2097642	FLUKE-700P29EX,I.S. PRE\$PTOOL	F700P	00 95969 24200 4
700P30	Gage Pressure Module (340 bar)	612165	FLUKE-700P30,PRESSURE PTOOL	F700P	00 95969 04578 0
700P31	Gage Pressure Module (700 bar)	612173	FLUKE-700P31,PRESSURE PTOOL	F700P	00 95969 04579 7
700PA3	Absolute Pressure Module (340 mbar)	612207	FLUKE-700PA3,PRESSURE PTOOL	F700P	00 95969 04619 0
700PA4	Absolute Pressure Module (1000 mbar)	612215	FLUKE-700PA4,PRESSURE PTOOL	F700P	00 95969 04620 6
700PA4Ex	Absolute Pressure Module (1000 mbar)	2097621	FLUKE-700PA4EX,I.S. PRE\$PTOOL	F700P	00 95969 24198 4
700PA5	Absolute Pressure Module (2 bar)	612223	FLUKE-700PA5,PRESSURE PTOOL	F700P	00 95969 04621 3
700PA6	Absolute Pressure Module (7 bar)	612231	FLUKE-700PA6,PRESSURE PTOOL	F700P	00 95969 04622 0
700PCK	Pressure Module Calibration Kit	100062	FLUKE-700PCK,PRESSURE PTOOL	F700A	00 95969 04243 7
700PD2	Dual Pressure Module (\pm 70 mbar)	612090	FLUKE-700PD2,PRESSURE PTOOL	F700P	00 95969 04561 2
700PD3	Dual Pressure Module (\pm 340 mbar)	612108	FLUKE-700PD3,PRESSURE PTOOL	F700P	00 95969 04562 9
700PD4	Dual Pressure Module (\pm 1000 mbar)	606837	FLUKE-700PD4,PRESSURE PTOOL	F700P	00 95969 04321 2
700PD5	Dual Pressure Module (-1000/+2000 mbar)	612116	FLUKE-700PD5,PRESSURE PTOOL	F700P	00 95969 04563 6
700PD6	Dual Pressure Module (-1000 mbar/+6.9 bar)	612124	FLUKE-700PD6,PRESSURE PTOOL	F700P	00 95969 04618 3
700PD7	Dual Pressure Module (-1000 mbar/+13.8 bar)	612132	FLUKE-700PD7,PRESSURE PTOOL	F700P	00 95969 04632 9
700PV3	Vacuum Pressure Module (-340 mbar)	612249	FLUKE-700PV3,PRESSURE PTOOL	F700P	00 95969 04623 7
700PV4	Vacuum Pressure Module(-1000 mbar)	612256	FLUKE-700PV4,PRESSURE PTOOL	F700P	00 95969 04624 4

Typ		Fluke Industrial			
Process Calibrator Accessories					
700BCA	Bar Code Adapter	656790	FLUKE-700BCA,BAR CODE PTOOL	F700A	00 95969 05678 6
700BCW	Bar Code Wand	647047	FLUKE-700BCW,BAR CODEPTOOL	F700A	00 95969 05432 4
700HTH-1	Hydraulic Test Hose	2811795	FLUKE-700HTH-1,HYDRAUPTOOL	F700A	00 95969 39773 5
700HTP-1	Hydraulic Test Pump	2811788	FLUKE-700HTP-1,HYDRAUIPTOOL	F700A	00 95969 39772 8
700ILF	In-Line Filter	1566730	FLUKE-700ILF,IN-LINE FIL PTOOL	F700A	00 95969 08727 8
700LTP-1	Low Pressure Test Pump	2811763	FLUKE-700LTP-1,LOW-PREPTOOL	F700A	00 95969 39770 4
700-IV	Current Shunt	202561	FLUKE-700-IV,CURRENT SIPTOOL	F700A	00 95969 04589 6
700PMP	Pressure Pump (10 bar)	617131	FLUKE-700PMP,PRESSURE PTOOL	F700A	00 95969 04799 9
700PRV-1	Pressure Relief Valve for 700HTP	2811808	FLUKE-700PRV-1,PRESSURPTOOL	F700A	00 95969 39774 2
700PTP-1	Pneumatic Test Pump	2811774	FLUKE-700PTP-1,PNEUMA PTOOL	F700A	00 95969 39771 1
700SC	Serial Interface Cable (Fluke 725/725Ex/726)	667425	FLUKE-700SC,CABLE ASSE PTOOL	F700A	00 95969 07135 2
700SW	DPC/Track Software	606795	FLUKE-700SW,DPC/TRACKPTOOL	F700S	00 95969 04613 8
700TC1	Thermocouple Plug Kits (10 types)	620119	FLUKE-700TC1,TC MINI-PIPTOOL	F700A	00 95969 05079 1
700TC2	Thermocouple Plug Kits (5 types)	620127	FLUKE-700TC2,T/C MINI-PPTOOL	F700A	00 95969 05080 7
744V20	HART Upgrade	1586561	FLUKE-744V20,HART UPGFPTOOL	F700A	00 95969 09417 7
787CAL 230	Calibration Module (Fluke 787)	662996	FLUKE-787CAL230,CALIBRPPTOOL	F700A	00 95969 06397 5
BC7217	Battery Charger	668217	BC7217 INTL,BATTERY CHPTOOL	F700A	00 95969 06628 0
BE9005 220	Battery Eliminator	946657	BE9005 220,BATTERY ELIPIPTOOL	F700A	00 95969 02474 7
BP7217	NiCd Battery Pack – obsolete > go BP7235	946660	BP7217,NICAD BATTERY PPTOOL	F700A	00 95969 02475 4
BP7235	NiMH Battery Pack	668225	BP7235,NIMH BATTERY P/PTOOL	F700A	00 95969 06629 7
C700	Hard Case (700 Series)	606928	C700,HARD CARRYING CA PTOOL	F700A	00 95969 04334 2
C789	Soft Meter Case	946694	C789,SOFT CARRYING CA S ACC	CASE	00 95969 02508 9
FVF-SC2	FlukeView Forms Software + IR USB-Cable (180 Series, 1653, 789, 1550)	1576734	FVF-SC2,FLUKEVIEW FORNACC	FLSW	00 95969 09048 3
FVF-Basic	FlukeView Forms Basic + IR USB cable (189, 287, 289, 789, 1550B)	2396957	FVF-BASIC,FLUKEVIEW FOACC	FLSW	00 95969 28323 6
IR189USB	IR Cable - USB (280/180 Series, 1653, 789, 1550B)	2428108	IR189USB, USB CABLE FOIACC	FLSW	00 95969 28870 5
General Accessories					
Test Leads, Probes and Clips					
AC72	Alligator Clip Set (1000V)	1670095	AC72,ALLIGATOR CLIP SE ACC	LEAD	00 95969 13321 0
AC87	Heavy Duty Bus Bar Clip Set	1278079	AC87,TEST LEAD ACCESSACC	LEAD	00 95969 07732 3
AC89	Heavy Duty Insulation Piercing Test Clip	873448	AC89,INSULATION PIERCIACC	LEAD	00 95969 01228 7
AC220	SureGrip Alligator Clip Set	1610103	AC220,SUREGRIP ALLIGATAACC	LEAD	00 95969 10339 8
AC280	SureGrip Hook Clip Set	1610115	AC280,SUREGRIP HOOK CIACC	LEAD	00 95969 10340 4
AC283	SureGrip Pincer Clip Set	1610144	AC283,SUREGRIP PINCER ACC	LEAD	00 95969 10341 1
AC285	SureGrip Alligator Clip Set	1610159	AC285,SUREGRIP LARGE AACC	LEAD	00 95969 10342 8
ACC-T5 Kit	Accessory kit for use with T5	2096971	T5-KIT,T5 TESTER ACCESSACC	KITS	00 95969 24181 6
BP980	Dual Banana Plug Kit	1616807	BP980,DUAL BANANA PLU(ACC	LEAD	00 95969 10700 6

Typ	Fluke Industrial					
H900	Test Lead Holder	1616818	H900,TEST LEAD HOLDER ACC	LEAD	00 95969 10701 3	
TL27	Heavy Duty Test Lead Set	668571	TL27,HEAVY DUTY TEST LACC	LEAD	00 95969 07673 9	
TL40	Retractable Tip Test Lead Set	1590606	TL40,RETRACTABLE TIP TIACC	LEAD	00 95969 09618 8	
TL71	Test Lead Set	1274382	TL71, TEST LEAD SET,PREACC	LEAD	00 95969 07729 3	
TL75	Hard Point Test Lead Set	855705	TL75,TEST LEAD SET ACC	LEAD	00 95969 01158 7	
TL76	All-in-one Test Lead Set	2032684	TL76,2/4 MM PROBE AND ACC	LEAD	00 95969 20760 7	
TL80A	Basic Electronic Test Lead Kit	1277086	TL80A,TEST LEAD SET,BA:ACC	LEAD	00 95969 07730 9	
TL81A	Deluxe Electronic Test Lead Kit	1277073	TL81A,TEST LEAD SET,DEIACC	LEAD	00 95969 07954 9	
TL175	TL175,TWISTGUARDTM TEST LEADS, 2MM DIA PROBE TIPS	3521976		0 ACC LEAD	0 95969 52154 3	
TL175E	TL175E, TWISTGUARDTM TEST LEADS, 2MM DIA PROBE TIPS WITH 4M	3565554		0 ACC LEAD	0 95969 52888 7	
TL220	SureGrip Industrial Test Lead Kit	2003625	TL220,SUREGRIP INDUSTFACC	KITS	00 95969 20645 7	
TL221	SureGrip Extension Lead Set	2003602	TL221,SUREGRIP SILICONACC	LEAD	00 95969 20643 3	
TL222	SureGrip Silicone Test Lead Set	2003616	TL222,SUREGRIP SILICONACC	LEAD	00 95969 20644 0	
TL223	SureGrip Electrical Test Lead Kit	2003633	TL223,SUREGRIP ELECTRIACC	KITS	00 95969 20646 4	
TL224	SureGrip Silicone Test Lead Set	1610198	TL224,SUREGRIP SILICONACC	LEAD	00 95969 10344 2	
TL238	SureGrip High Energy Test Lead Kit	2132831	TL238,TEST LEAD SET FOIACC	KITS	00 95969 25541 7	
TL910	Electronic Test Lead Set (with replacement tips)	1616632	TL910,ELECTRONIC TEST ACC	LEAD	00 95969 10688 7	
TL930	Patch Cords (60 cm)	1616671	TL930,24 INCH PATCH CO ACC	LEAD	00 95969 10692 4	
TL932	Patch Cords (90 cm)	1616680	TL932,36 INCH PATCH CO ACC	LEAD	00 95969 10693 1	
TL935	Patch Cord Kit (60, 90, 120 cm)	1616698	TL935,PATCH CORD KIT ACC	LEAD	00 95969 10694 8	
TL940	Mini-Hook Test Lead Set	1616705	TL940,MINI-HOOK TEST LACC	LEAD	00 95969 10695 5	
TL950	Mini-Pincer Test Lead Set	1616710	TL950,MINI-PINCER TEST ACC	LEAD	00 95969 10696 2	
TL960	Micro-Hook Test Lead Set	1616722	TL960,MICRO-HOOK TESTACC	LEAD	00 95969 10697 9	
TL970	Hook and Pincer Test Lead Kit	1616793	TL970,HOOK AND PINCER ACC	LEAD	00 95969 10699 3	
TLK220	SureGrip Accessory Kit	2097022	TLK-220 EUR,SUREGRIP A:ACC	KITS	00 95969 24186 1	
TLK225	SureGrip Master Accessory Kit	2097031	TLK-225,SUREGRIP MASTEACC	KITS	00 95969 24187 8	
TLK290	Test Probe Kit	2435092	TLK290,PHASE ROTATIONACC	KITS	00 95969 29140 8	
TLK287	Electronic Master Test Lead Kit	3045631	TLK287,ELECTRONICS MA:ACC	KITS	00 95969 41785 3	
TLK289	Industrial Master Test Lead Kit	3092521	TLK289 EUR,INDUSTRIAL ACC	KITS	00 95969 43644 1	
TLK291	Fused Test Probe Set	2435108	TLK291,FUSED TEST PROEACC	KITS	00 95969 29141 5	
TP1	Slim Reach Test Probe Set (flat blade)	650887	TP1,TEST PROBES, SLIM-FACC	LEAD	00 95969 05769 1	
TP2	Slim Reach Test Probe Set (2 mm)	650892	TP2,TEST PROBES, SLIM-FACC	LEAD	00 95969 05770 7	
TP4	Slim Reach Test Probe Set (4 mm)	650895	TP4,TEST PROBES, SLIM-FACC	LEAD	00 95969 05771 4	
TP38	Slim Reach Test Probe Set (insulated)	1541636	TP38,INSULATED TEST PRACC	LEAD	00 95969 07877 1	
TP74	Lantern Tip Test Probe Set	1541649	TP74, TEST LEAD ACCESSIACC	LEAD	00 95969 07878 8	
TP80	Electronic Test Probe Set	873455	TP80,ELECTRONIC TEST PACC	LEAD	00 95969 01230 0	
TP220	SureGrip Test Probe Set	1670056	TP220,SUREGRIP TEST PRACC	LEAD	00 95969 13320 3	
TP912	Replacement tips for TL910	1616644	TP912,REPLACEMENT TIP:ACC	LEAD	00 95969 10689 4	

Typ	Fluke Industrial				
TP920	Test Probe Adapter Kit	1616659	TP920,TEST PROBE ADAPTIACC	LEAD	00 95969 10690 0
FTP	Fused Test Probes	3274829			
FTPL	Fused Test Probes with test leads	3460786			
Current Clamps					
80i-110s	AC/DC Current Clamp (100 A)	114519	80I-110S,AC/DC CURRENTSCM	SMACC	00 95969 04054 9
90i-610s	AC/DC Current Clamp (600 A)	201258	90I-610S,AC/DC CURRENTSCM	98ACC	00 95969 04309 0
i30	AC/DC Current Clamp (30A)	2584920	I30,AC/DC CURRENT CLAMACC	LPRST	00 95969 34509 5
i30s	AC/DC Current Clamp (30A)	2584935	I30S,AC/DC CURRENT CLAACC	LPRST	00 95969 34510 1
i50s	AC Current Clamp (50 MHz)	2840290	I50S,AC/DC SCOPE CURREACC	LPRST	00 95969 40123 4
PSi50s	Bench Power Supply Module	3029986	PSI50S,BENCH POWER SU ACC	LPRST	00 95969 41642 9
i200	AC Current Clamp (200 A)	664755	I200,200 AMP CLAMP, CUFACE	PRCU	00 95969 06393 7
i200s	AC Current Clamp (200 A)	664760	I200S,200 AMP CLAMP, VCACC	PRCU	00 95969 06394 4
i310s	AC/DC Current Clamp (300A)	2840309	I310S,AC/DC CURRENT CLACC	LPRST	00 95969 40124 1
i400	AC Current Clamp (400 A)	2277225	I400,AC CURRENT CLAMP-ACC	PRCU	00 95969 26860 8
i400s	AC Current Clamp (400A)	2277202	I400S,AC CURRENT CLAMFACE	PRCU	00 95969 26858 5
i410	AC/DC Current Clamp (400 A)	617727	I410,400A AC/DC CURRENACC	PRCU	00 95969 04819 4
i410 Kit	AC/DC Current Clamp (400 A) with Soft Case	2097005	I410-KIT,AC/DC CURRENT ACC	PRCU	00 95969 24184 7
i800	AC Current Clamp (800 A)	2840283	I800,AC CURRENT CLAMP ACC	PRCU	00 95969 40122 7
i1010	AC/DC Current Clamp (1000 A)	617735	I1010,AC/DC CURRENT CLACC	PRCU	00 95969 04820 0
i1010 Kit	AC/DC Current Clamp (1000 A) with Soft Case	2096998	I1010-KIT,AC/DC CURRENACC	PRCU	00 95969 24183 0
i1000s	AC Current Clamp (1000 A)	1568487	I1000S,AC CURRENT CLAMACC	PRCU	00 95969 09047 6
i2000 flex	AC Flexible Current Clamp (2000 A)	2584912	I2000 FLEX,AC CURRENT FACE	PRCU	00 95969 34508 8
i3000s	AC Current Clamp (3000 A)	657202	I3000S,AC CURRENT CLAMACC	PRCU	00 95969 06202 2
i3000s flex-24	AC Flexible Current Clamp (3000 A), 610 mm	2584888	I3000S FLEX-24,AC CURREACC	LPRST	00 95969 34505 7
i3000s flex-36	AC Flexible Current Clamp (3000 A), 915 mm	2584901	I3000S FLEX-36,AC CURREACC	LPRST	00 95969 34507 1
i3000 flex-4PK	AC Flexible Current Clamp (3000 A), 4-pack	2696367	I3000 FLEX-4PK,AC CURREACC	PRCU	00 95969 36247 4
i6000s flex-24	AC Current Clamp (6000 A)	2840311	I6000S FLEX-24,AC CURREACC	LPRST	00 95969 40125 8
i6000s flex-36	AC Current Clamp (6000 A)	2840327	I6000S FLEX-36,AC CURREACC	LPRST	00 95969 40126 5
Temperature Accessories					
80AK-A	Thermocouple Adapter	2747812	80AK-A,TYPE K, THERMOCACC	PRTPT	00 95969 37097 4
80BK-A	Integrated DMM Temperature Probe (Type K)	2747801	80BK-A,TYPE K, INTEGRATACC	PRTPT	00 95969 37096 7
80CJ-M	Male Mini Connectors (Type J)	833046	80CJ-M,MINI THERMOCOLACC	PRTPT	00 95969 01128 0
80CK-M	Male Mini Connectors (Type K)	779942	80CK-M,MINI THERMOCOLACC	PRTPT	00 95969 01017 7
80PJ-1	Bead Probe (Type J)	1288191	80PJ-1, TYPE J BEAD PROFACE	PRTPT	00 95969 07844 3
80PJ-9	General Purpose Probe (Type J)	1288218	80PJ-9,TYPE J LANCE TIP IACC	PRTPT	00 95969 07846 7
80PJ-EXT	Extension Wire Kit (Type J)	1288234	80PJ-EXT,TYPE J EXTENSIACC	PRTPT	00 95969 07848 1
80PK-1	Bead Probe (Type K)	750422	80PK-1,PROBE, THERMOCACC	PRTPT	00 95969 00974 4

Typ	Fluke Industrial				
80PK-3A	Surface Probe (Type K)	874610	80PK-3A,PROBE,SURFACE ACC	P RTP	00 95969 01237 9
80PK-8	Pipe Clamp Temperature Probe (Type K)	200360	80PK-8,TYPE-K, PIPE CLANACC	P RTP	00 95969 04077 8
80PK-9	General Purpose Probe (Type K)	1288229	80PK-9,TYPE K LANCE TIP ACC	P RTP	00 95969 07847 4
80PK-11	Velcro Temperature Probe	2724500	80PK-11,K-TYPE VELCRO TACC	P RTP	00 95969 36436 2
80PK-18 Kit	Pipe Clamp Temperature Probe Kit	3448859	80PK-18,TYPE K PIPE CLAIACC	P RTP	00 95969 49382 6
80PK-22	SureGrip Immersion Probe	2098684	80PK-22,SUREGRIP, IMME ACC	P RTP	00 95969 24268 4
80PK-24	SureGrip Air Probe	2098691	80PK-24,SUREGRIP, AIR T ACC	P RTP	00 95969 24269 1
80PK-25	SureGrip Piercing Probe	2098706	80PK-25,SUREGRIP, PIERCACC	P RTP	00 95969 24270 7
80PK-26	SureGrip General Purpose Probe	2098714	80PK-26, SUREGRIP, TAPEACC	P RTP	00 95969 24271 4
80PK-27	SureGrip Industrial Surface Probe	2098723	80PK-27,SUREGRIP, INDU:ACC	P RTP	00 95969 24272 1
80PK-EXT	Extension Wire Kit (Type K)	1288241	80PK-EXT,TYPE K EXTENS:ACC	P RTP	00 95969 07849 8
80PR-60	RTD Temperature Probe (Fluke 66/68)	2148313	80PR-60, IR-PISTOL-RTD IACC	P RTP	00 95969 26117 3
80PT-25	SureGrip Piercing Probe	2104397	80PT-25,SUREGRIP, PIERCACC	P RTP	00 95969 24496 1
80PT-EXT	Extension Wire Kit (Type T)	1288252	80PT-EXT,TYPE T EXTENS:ACC	P RTP	00 95969 07850 4
80T-150UA	Universal Temperature Probe (for DMMs)	3190456	80T-150UA,PROBE,TEMPEIACC	P RTP	00 95969 44661 7
80TK	Thermocouple Module (Type K)	736736	80TK,THERMOCOUPLE MCACC	P RTP	00 95969 00942 3
80PK-10	Pipe Clamp Temperature Probe	3439199			
80PK-18	Pipe Clamp Temperature Probe Kit	3448859			
Cases and Holsters					
C10	Meter Holster	897744	C10,HOLSTER ACC	CASE	00 95969 01387 1
C12A	Soft Meter Case	930529	C12A,SOFT CARRYING CA:ACC	CASE	00 95969 02825 7
C20	Hard Meter Case	708396	C20,HARD CARRYING CAS ACC	CASE	00 95969 00652 1
C23	Soft Meter Case	1663209	C23,SOFT CASE,VINYL,BL/ACC	CASE	00 95969 13007 3
C25	Soft Meter Case	681114	C25,SOFT CASE FOR FLUKACC	CASE	00 95969 00637 8
C33	Soft Meter Case	1664120	C33,SOFT CASE,VINYL,BL/ACC	CASE	00 95969 13020 2
C35	Soft Meter Case	2826056	C35,CARRYING CASE, POL ACC	CASE	00 95969 40007 7
C43	Soft Meter Case	1663230	C43,SOFT CARRYING CAS:ACC	CASE	00 95969 13008 0
C50	Soft Meter Case	762823	C50,CARRYING CASE ACC	CASE	00 95969 00987 4
C75	Soft Accessory Case	865535	C75,CARRYING CASE ACC	CASE	00 95969 01201 0
C90	Soft Meter Case	466029	C90,CARRYING CASE ACC	CASE	00 95969 00353 7
C100	Hard Meter and Accessory Case	827055	C100,UNIVERSAL CARRYINACC	CASE	00 95969 01064 1
C101	Hard Case	2437514	C101,HARD CASE ACC	CASE	00 95969 29174 3
C115	Soft Meter Case	2826063	C115,CARRYING CASE, POACC	CASE	00 95969 40008 4
C116	Soft Meter Case	2826074	C116,CARRYING CASE, POACC	CASE	00 95969 40009 1
C120	Hard Case (43B/120 Series)	646189	C120,HARD CARRYING CA:SCM	12ACC	00 95969 05214 6
C125	Soft Meter Case	646858	C125,COMPACT SOFT CAS:SCM	12ACC	00 95969 05289 4
C190	Hard Case (190 Series)	677401	C190,HARDCASE SM 190 SSCM	SMACC	00 95969 07574 9
C195	Soft Case	677408	C195,SOFTCASE SCM	SMACC	00 95969 07575 6

Typ	Fluke Industrial				
C280	Soft Meter Case	3182785	C280,CARRYING CASE, POACC	CASE	00 95969 44380 7
C345	Soft Case	3311173	C345,SOFT CARRYING CASEACC	CASE	00 95969 46364 5
C510	Leather Meter Case	1547885	C510,METER CASE,LEATHIACC	CASE	00 95969 08061 3
C520A	Leather Tester Case	1629104	C520A,TESTER CASE,LEATAACC	CASE	00 95969 11097 6
C550	Tool Bag	1547919	C550,PREMIUM TOOL BAGACC	CASE	00 95969 08064 4
C570	Soft Case (572, 574, 576)	2436565	C570,SOFT CASE, 57X SERACC	CASE	00 95969 29155 2
C781	Soft Meter Case	619988	C781,SOFT CARRYING CASEACC	CASE	00 95969 04841 5
C789	Soft Meter Case	946694	C789,SOFT CARRYING CASEACC	CASE	00 95969 02508 9
C800	Hard Meter and Accessory Case	896220	C800,CARRYING CASE ACC	CASE	00 95969 01338 3
C1600	Meter and Accessory Case	2091049	C1600,METER GEAR BOX ACC	CASE	00 95969 24065 9
CXT80	Rugged Pelican Hard Case	3352559	CXT80,RUGGED PELICAN HACC	CASE	00 95969 47293 7
CXT170	Rugged Pelican Hard Case	3352567	CXT170,RUGGED PELICAN ACC	CASE	00 95969 47294 4
CXT280	Rugged Pelican Hard Case	3352571	CXT280,RUGGED PELICAN ACC	CASE	00 95969 47295 1
H3	Holster (330 Series)	1608458	H3,HOLSTER WITH ACCESACC	CASE	00 95969 10272 8
H5	Electrical Tester Holster (Fluke T5)	649365	H5,HOLSTER,BELT,ACCESACC	CASE	00 95969 05719 6
H6	Infrared Thermometer Holster (Fluke 63/65/68/561)	2152040	H6, IR-PISTOL-HOLSTER ACC	CASE	00 95969 26188 3
H80M	Holster + Magnetic Hanger	2138458	H80M,PROTECTIVE HOLSTACC	CASE	00 95969 25725 1
Automotive Accessories					
BP880	BNC to Female Double Stacking Banana Plug	2150594	BP880,BNC FEMALE TO DCACC	AUTAC	00 95969 26146 3
BP881	BNC to Male Double Stacking Banana Plug	2151015	BP881,BNC MALE TO DOUIACC	AUTAC	00 95969 26160 9
PV350	Pressure Vacuum Module	919811	PV350,PRESSURE/VACUUMACC	PVM	00 95969 01706 0
RPM80	Inductive Pick-up	880849	RPM80,INDUCTIVE PICK-UACC	AUTAC	00 95969 01205 8
TAS90	Automotive Accessory Set (120/190 Series)	614187	TAS90,SHIELDED TEST LE SCM	SMACC	00 95969 04764 7
TL28A	Automotive Test Lead Set	1273185	TL28A,HEAVY DUTY TEST ACC	LEAD	00 95969 08353 9
TL82	Automotive Pin and Socket Adapter Set	2150636	TL82,AUTOMOTIVE PIN AACC	AUTAC	00 95969 26147 0
TLK281	Suregrip Automotive Test Lead Kit	2150715	TLK281,AUTOMOTIVE TESACC	AUTAC	00 95969 26150 0
TLK282	SureGrip Deluxe Automotive Test Lead Kit	2150744	TLK282,DELUXE AUTOMOTACC	AUTAC	00 95969 26151 7
TP40	Automotive Back Probe Pins (5 pcs) (4 mm)	1567573	TP40,AUTOMOTIVE BACK ACC	AUTAC	00 95969 08751 3
TP81	Insulation Piercing Clip Set (4 mm)	2149098	TP81,INSULATION PIERCIACC	AUTAC	00 95969 26127 2
TP82	Insulation Piercing Clip Set (2 mm)	2149080	TP82,INSULATION PIERCIACC	AUTAC	00 95969 26126 5
TP84	Oxygen Sensor Insulation Piercing Clip (4 mm)	2149116	TP84,OXYGEN SENSOR INACC	AUTAC	00 95969 26129 6
TP88	Rigid Back Probe Pin Set	2149102	TP88,RIGID BACKPROBE PACC	AUTAC	00 95969 26128 9
SCC128	Automotive Accessory Kit (120 Series)	2100199	SCC 128,AUTOMOTIVE ACSCM	SMACC	00 95969 24313 1
SCC198	Automotive Accessory Kit (190 Series)	2100208	SCC 198,AUTOMOTIVE ACSCM	SMACC	00 95969 24314 8
STL90	Automotive Shielded Test Lead Set (120/190 Series)	201233	STL90,SHIELDED TESTLEASCM	98ACC	00 95969 04307 6
90i-610s	AC/DC Current Clamp (600 A)	201258	90I-610S,AC/DC CURRENTSCM	98ACC	00 95969 04309 0
Other Accessories					

Typ	Fluke Industrial				
80K-6	High Voltage Probe	532424	80K-6,PROBE, HIGH VOLT.ACC	PRHV	00 95969 00533 3
80K-40	High Voltage Probe	382846	80K-40,PROBE, HIGH VOL.ACC	PRHV	00 95969 00112 0
AN5	Analog Data Cable (574, 576)	2437178	AN5,CABLE, ANALOG OUTIACC	MISC	00 95969 29170 5
BP189	High Capacity Battery Enclosure (Fluke 189)	2407248	BP189,HIGH CAPACITY BAACC	MISC	00 95969 28465 3
FOM	Fiber Optic Meter	200428	FOM,FIBER OPTIC METER ACC	FIBO	00 95969 04627 5
FOS-850	Fiber Optic Light Source	200433	FOS-850,FIBER OPTIC SOIACC	FIBO	00 95969 04628 2
FOS-850/1300	Fiber Optic Light Source	200441	FOS-850/1300,FIBER OPTIACC	FIBO	00 95969 04630 5
TPAK	ToolPak, Meter Hanging Kit	1281997	TPAK,METER HANGING KI ACC	HANG	00 95969 08263 1
L200	Probe Light	2096346	L200,PROBE LIGHT ACC	LIGHT	00 95969 24166 3
L205	Mini Hat Light	2098588	L205,MINI HAT LIGHT ACC	LIGHT	00 95969 24260 8
L206	Deluxe Hat Light	2098595	L206,DELUXE LED HAT LICACC	LIGHT	00 95969 24261 5
L210	Probe light and probe extender	2096379	L210,PROBE LIGHT AND PACC	LIGHT	00 95969 24169 4
L215	SureGrip kit with probe light and probe extender	2096368	L215,SUREGRIP KIT WITHACC	LIGHT	00 95969 24168 7
MC6	MeterCleaner Wipes, 6-pack	2092212	MC6,METERCLEANER WIPIACC	MISC	00 95969 24100 7
MC50	MeterCleaner Wipes, 50-pack	2092300	MC50,METERCLEANER WIIACC	MISC	00 95969 24101 4
PV350	Pressure Vacuum Module	919811	PV350,PRESSURE/VACUUMACC	PVM	00 95969 01706 0
SV225	Stray Voltage Adapter	3100477	SV225,STRAY VOLTAGE ELACC	MISC	00 95969 43766 0
TL225	SureGrip Stray Voltage Adapter Test Lead Kit	2429268	TL225,STRAY VOLTAGE ELACC	KITS	00 95969 28878 1
Fuse 44/100A	0.440 A, 1000 V, FAST, Interrupt rating 10 kA, 10.3x34.9mm	943121	FUSE,.440A,1000V,FAST,.4PARTS	PARTS	00 95969 08990 6
Fuse 11A	11 A, 1000 V, FAST, Interrupt rating 20 kA, 10.3x38.1mm	803293	FUSE,11A,1000V,FAST.406PARTS	PARTS	00 95969 095761
	892583 Fuse, A:15A (F), V:600V, IR:100kA, 10.3x38.1 mm	892583	FUSE-15A/600BLSTR,FUSEPARTS	PARTS	00 95969 01265 2
	830828 Fuse, A:1A (F), V:600V, IR:10kA, 10.3x34.9 mm	830828	FUSE,FUSE,.406X1.375,1A PARTS	NEW	00 95969 09616 4
	2279339 Fuse, A:315mA (f), V:1000V, IR:10kA, 6.35x32 mm	2279339	7017240.0,315,FUSE,315 IPARTS	NEW	00 95969 34811 9
	740670 Fuse, A:630mA (F), V:250V, IR:1500A, 5x20 mm	740670	FUSE,FUSE,5X20MM,0.63APARTS	PARTS	00 95969 09615 7
	659059 Input Receptable Assembly (Fluke-89/-180-Series/-789)	659059	FLUKE 89-4-8002,INPUT RPARTS	PARTS	
	826214 Input Receptable Assembly (Fluke 80-Series - excl. Fluke-89)	826214	FLUKE 87-8009,INPUT RCFPARTS	NEW	
Software					
FVF-Basic	FlukeView Forms Basic + IR USB cable (189, 789, 1550B)	2396957	FVF-BASIC,FLUKEVIEW FOACC	FLSW	00 95969 28323 6
FVF-SC1	FlukeView Forms Software + Cable (Fluke 53II/54II/87 IV/89 IV)	1576285	FVF-SC1,FLUKEVIEW FORIACC	FLSW	00 95969 09044 5
FVF-SC2	FlukeView Forms Software + IR USB-Cable (180 Series, 1653, 789, 1550)	1576734	FVF-SC2,FLUKEVIEW FORIACC	FLSW	00 95969 09048 3
FVF-SC3	FlukeView Forms Software + Cable (Fluke 45)	1675167	FVF-SC3,FLUKEVIEW FORIACC	FLSW	00 95969 13543 6
FVF-SC4	FlukeView Forms Software + Cable (8845A/8846A)	2687335	FVF-SC4,FLUKEVIEW FORIACC	FLSW	00 95969 36181 1
FVF-SC5	FlukeView Forms Basic (8845A/8846A)	2791314	FVF-SC5,FLUKEVIEW FORIACC	FLSW	00 95969 39079 8
FVF-UG	FlukeView Forms Upgrade	1576741	FVF-UG,FLUKEVIEW FORMACC	FLSW	00 95969 09046 9
IR189USB	IR Cable - USB (180 Series, 1653, 789, 1550B)	2428108	IR189USB, USB CABLE FOIACC	FLSW	00 95969 28870 5

Typ	Fluke Industrial				
SCC120E	FlukeView Software + USB Cable + Case (120 Series) - English	646684	SCC120E,SOFTWARE&CABSCM	12ACC	00 95969 05265 8
SCC190	FlukeView Software + Cable + Case (190 Series) - English, French, German	671826	SCC190EFG,SW & CABLE CSM	SMACC	00 95969 07560 2
SW43W	FlukeView Software (Fluke 43B/430 Series)	2098918	SW43W,FLUKEVIEW 43 SCFPQ	PQP	00 95969 24280 6
SW90W/034	FlukeView ScopeMeter Software (English, French, German)	1641990	SW90W/034EFG,FLUKEVIESCM	SMACC	00 95969 11808 8
700SW	DPC/Track Software	606795	FLUKE-700SW,DPC/TRACKPTOOL	F700S	00 95969 04613 8
Fluke Bench Instruments					
Counters					
PM6681/016	Timer/counter (300 MHz, 50 ps)	101953	PM6681/016,TIMER/COUNTI	PKIST	00 95969 02726 7
PM6681/056	Timer/counter (300 MHz, 50 ps)	101979	PM6681/056,TIMER/COUNTI	PKIST	00 95969 02729 8
PM6681/066	Timer/counter (300 MHz, 50 ps)	651874	PM6681/066,TIMER/COUNTI	PKIST	00 95969 05621 2
PM6681/616	Timer/counter (300 MHz/2.7 GHz, 50 ps)	102004	PM6681/616,TIMER/COUNTI	PKIST	00 95969 02734 2
PM6681/656	Timer/counter (300 MHz/2.7 GHz, 50 ps)	102027	PM6681/656,TIMER/COUNTI	PKIST	00 95969 02737 3
PM6681/666	Timer/counter (300 MHz/2.7 GHz, 50 ps)	651890	PM6681/666,TIMER/COUNTI	PKIST	00 95969 05623 6
PM6681/716	Timer/counter (300 MHz/8 GHz, standard timebase)	2464079	PM6681/716,TIMER-COUNTI	PKIST	00 95969 29697 7
PM6681/766	Timer/counter (300 MHz/8 GHz, HS OCXO)	2464093	PM6681/766,TIMER-COUNTI	PKIST	00 95969 29699 1
PM6681/756	Timer/counter (300 MHz/8 GHz, OCXO)	2464087	PM6681/756,TIMER-COUNTI	PKIST	00 95969 29698 4
PM6681R/076	Frequency counter/calibrator (300 MHz)	610920	PM6681R/076,TIMER/COUITI	PKIST	00 95969 04551 3
PM6681R/676	Frequency counter/calibrator (300 MHz/2.7 GHz)	610946	PM6681R/676,TIMER/COUITI	PKIST	00 95969 04553 7
PM6685/011	Frequency counter (300 MHz)	934377	PM6685/011,FREQ. COUN'ITI	PKIST	00 95969 02032 9
PM6685/013	Frequency counter (300 MHz)	934380	PM6685/013,FREQ. COUN'ITI	PKIST	00 95969 02033 6
PM6685/016	Frequency counter (300 MHz)	934385	PM6685/016,FREQ. COUN'ITI	PKIST	00 95969 02034 3
PM6681R/776	Frequency counter calibrator (300 MHz/8 GHz), Rubidium	2464101	PM6681R/776,TIMER-COUITI	PKIST	00 95969 29700 4
PM6685/051	Frequency counter (300 MHz)	934435	PM6685/051,FREQ. COUN'ITI	PKIST	00 95969 02056 5
PM6685/053	Frequency counter (300 MHz)	934443	PM6685/053,FREQ. COUN'ITI	PKIST	00 95969 02057 2
PM6685/056	Frequency counter (300 MHz)	934448	PM6685/056,FREQ. COUN'ITI	PKIST	00 95969 02058 9
PM6685/061	Frequency counter (300 MHz)	651924	PM6685/061,FREQ. COUN'ITI	PKIST	00 95969 05626 7
PM6685/063	Frequency counter (300 MHz)	655628	PM6685/063,FREQ. COUN'ITI	PKIST	00 95969 05627 4
PM6685/066	Frequency counter (300 MHz)	655636	PM6685/066,FREQ. COUN'ITI	PKIST	00 95969 05628 1
PM6685/611	Frequency counter (300 MHz/2.7 GHz)	934575	PM6685/611, FREQ. COUNITI	PKIST	00 95969 02089 3
PM6685/613	Frequency counter (300 MHz/2.7 GHz)	934583	PM6685/613, FREQ. COUNITI	PKIST	00 95969 02095 4
PM6685/616	Frequency counter (300 MHz/2.7 GHz)	934588	PM6685/616, FREQ. COUNITI	PKIST	00 95969 02096 1
PM6685/651	Frequency counter (300 MHz/2.7 GHz)	934633	PM6685/651, FREQ. COUNITI	PKIST	00 95969 02109 8
PM6685/653	Frequency counter (300 MHz/2.7 GHz)	934638	PM6685/653, FREQ. COUNITI	PKIST	00 95969 02110 4
PM6685/656	Frequency counter (300 MHz/2.7 GHz)	934641	PM6685/656, FREQ. COUNITI	PKIST	00 95969 02111 1
PM6685/661	Frequency counter (300 MHz/2.7 GHz)	655693	PM6685/661, FREQ. COUNITI	PKIST	00 95969 05634 2
PM6685/663	Frequency counter (300 MHz/2.7 GHz)	655701	PM6685/663, FREQ. COUNITI	PKIST	00 95969 05635 9
PM6685/666	Frequency counter (300 MHz/2.7 GHz)	655719	PM6685/666, FREQ. COUNITI	PKIST	00 95969 05636 6

Typ	Fluke Industrial				
PM6685R/071	Frequency counter/calibrator (300 MHz)	102459	PM6685R/071,FREQ. COUNITI	PKIST	00 95969 02738 0
PM6685R/076	Frequency counter/calibrator (300 MHz)	102464	PM6685R/076,FREQ. COUNITI	PKIST	00 95969 02739 7
PM6685R/671	Frequency counter/calibrator (300 MHz/2.7 GHz)	102475	PM6685R/671,FREQ. COUNITI	PKIST	00 95969 02742 7
PM6685R/676	Frequency counter/calibrator (300 MHz/2.7 GHz)	102480	PM6685R/676,COUNTER, 2ITI	PKIST	00 95969 02743 4
PM6690/011	Timer/Counter (300 MHz, std. timibase)	2463886	PM6690/011,TIMER-COUNITI	PKIST	00 95969 29678 6
PM6690/012	Timer/Counter (300 MHz, std. timebase, rear inputs)	2463899	PM6690/012,TIMER-COUNITI	PKIST	00 95969 29679 3
PM6690/051	Timer/Counter (300 MHz, OCXO)	2463900	PM6690/051,TIMER-COUNITI	PKIST	00 95969 29680 9
PM6690/052	Timer/Counter (300 MHz, OXCO, rear inputs)	2463917	PM6690/052,TIMER-COUNITI	PKIST	00 95969 29681 6
PM6690/061	Timer/Counter (300 MHz, HS OCXO)	2463921	PM6690/061,TIMER-COUNITI	PKIST	00 95969 29682 3
PM6690/062	Timer/Counter (300 MHz, HS OCXO, rear inputs)	2463939	PM6690/062,TIMER-COUNITI	PKIST	00 95969 29683 0
PM6690/611	Timer/Counter (300 MHz/3 GHz, std. timebase)	2463942	PM6690/611,TIMER-COUNITI	PKIST	00 95969 29684 7
PM6690/612	Timer/Counter (300 MHz/3 GHz, std. timebase, rear inputs)	2463956	PM6690/612,TIMER-COUNITI	PKIST	00 95969 29685 4
PM6690/651	Timer/Counter (300 MHz/3 GHz, OCXO)	2463963	PM6690/651,TIMER-COUNITI	PKIST	00 95969 29686 1
PM6690/652	Timer/Counter (300 MHz/3 GHz, OCXO, rear inputs)	2463974	PM6690/652,TIMER-COUNITI	PKIST	00 95969 29687 8
PM6690/661	Timer/Counter (300 MHz/3 GHz, HS OCXO)	2463988	PM6690/661,TIMER-COUNITI	PKIST	00 95969 29688 5
PM6690/662	Timer/Counter (300 MHz/3 GHz, HS OCXO, rear inputs)	2463995	PM6690/662,TIMER-COUNITI	PKIST	00 95969 29689 2
PM6690/711	Timer/Counter (300 MHz/8 GHz, std. timebase)	2464005	PM6690/711,TIMER-COUNITI	PKIST	00 95969 29690 8
PM6690/712	Timer/Counter (300 MHz/8 GHz, std. timebase, rear inputs)	2464010	PM6690/712,TIMER-COUNITI	PKIST	00 95969 29691 5
PM6690/751	Timer/Counter (300 MHz/8 GHz, OCXO)	2464022	PM6690/751,TIMER-COUNITI	PKIST	00 95969 29692 2
PM6690/752	Timer/Counter (300 MHz/8 GHz, OCXO, rear inputs)	2464031	PM6690/752,TIMER-COUNITI	PKIST	00 95969 29693 9
PM6690/761	Timer/Counter (300 MHz/8 GHz, HS OCXO)	2464046	PM6690/761,TIMER-COUNITI	PKIST	00 95969 29694 6
PM6690/762	Timer/Counter (300 MHz/8 GHz, HS OCXO, rear inputs)	2464054	PM6690/762,TIMER-COUNITI	PKIST	00 95969 29695 3
Counters Options/Accessories					
PM9604/001	GPIB interface (Counters)	102835	PM9604/001,PM9604 GPIBITI	PKIST	00 95969 10408 1
PM9606/011	Rackmount kit (Counters)	933085	PM9606/011,RACKMOUNT·ITI	PKIST	00 95969 02030 5
PM9606/021	Rackmount kit (Counters)	933093	PM9606/021,RACKMOUNT·ITI	PKIST	00 95969 02031 2
PM9607/001	MTCXO Time base (Counters)	102868	PM9607/001,PM9607 MTC·ITI	PKIST	00 95969 10409 8
PM9608/201	1.3 GHz input option (Counters)	869441	PM9608/201,1.3GHZ INPU·ITI	PKIST	00 95969 10410 4
PM9609/001	Carrying case (Counters)	840736	PM9609/001,CARRY CASE ITI	PKIST	00 95969 10484 5
PM9611/801	Rear inputs (PM6680)	924878	PM9611/801,REAR INPUT ITI	PKIST	00 95969 01626 1
PM9622/001	Rackmount kit (PM6680)	895271	PM9622/001,19 IN. RACKMITI	PKIST	00 95969 10533 0
PM9622/021	Rackmount kit (PM6685)	935473	PM9622/021,RACK KIT FO·ITI	PKIST	00 95969 02102 9
PM9623/001	Battery pack (PM6685)	935481	PM9623/001,BATTERY KIT·ITI	PKIST	00 95969 02104 3
PM9624/001	2.7 GHz input option (PM6680)	895276	PM9624/001,2.7GHZ INPU·ITI	PKIST	00 95969 10534 7
PM9626/001	GPIB interface (PM6680)	895284	PM9626/001,GPIB INTERF·ITI	PKIST	00 95969 10535 4
PM9626/021	GPIB interface (PM6685)	935510	PM9626/021,GPIB INTERF·ITI	PKIST	00 95969 02162 3
PM9627/001	Carrying case (PM6680 and PM6685)	935486	PM9627/001,CARRYING C·ITI	PKIST	00 95969 02105 0
PM9627H	Carrying case (Heavy duty)	1573745	PM9627H,HEAVY DUTY AL·ITI	PKIST	00 95969 08956 2

Typ	Fluke Industrial				
PM9638/001	RF input option, 8 GHz service option PM668x	2464208	PM9638/001,RF INPUT OPITI	PKIST	00 95969 29710 3
PM9651/001	Line voltage adapter/battery charger (Fluke 160 series)	624939	PM9651/001,AC/DC ADAPITI	PKIST	00 95969 05050 0
PM9651/008	Line voltage adapter/battery charger (Fluke 160 series)	624988	PM9651/008,AC/DC ADAPITI	PKIST	00 95969 05055 5
PM9691/011	High Stability Oscillator (PM668x)	103007	PM9691/011,PM9691 ULTFITI	PKIST	00 95969 10428 9
PM9692/011	Ultra-high Stability Oscillator (PM668x)	655800	PM9692/011,ULTRA-HI ST.ITI	PKIST	00 95969 05646 5
SW160W/011E	FlukeView multifunction counter software	614732	SW160W/011E,FLUKEVIEWITI	PKIST	00 95969 04885 9
TimeView-81W	TimeView Software for PM6681	2464199	TIMEVIEW-81W,TIMEVIEWITI	PKIST	00 95969 29709 7
TimeView-90W	TimeView software for PM6690	2464068	TIMEVIEW-90W,TIMEVIEWITI	PKIST	00 95969 29696 0
Video and TV Generators					
54100M01	Video signal generator (multi standard)	628062	54100M01/001,VIDEO SIGITI	PSIGN	00 95969 05114 9
54100M02	Video signal generator (multi standard)	677879	54100M02/001,VIDEO SIGITI	PSIGN	00 95969 07386 8
54100N01	Video signal generator (single standard)	628161	54100N01/001,VIDEO SIGITI	PSIGN	00 95969 05124 8
54100P01	Video signal generator (single standard)	628255	54100P01/001,VIDEO SIGITI	PSIGN	00 95969 05134 7
54100PN1	Video signal generator (dual standard)	677997	54100PN1/001,VIDEO SIGITI	PSIGN	00 95969 07410 0
54200M01	TV signal generator (multi standard)	624996	54200M01/001,TV SIGNALITI	PSIGN	00 95969 05057 9
54200M02	TV signal generator (multi standard)	676780	54200M02/001,TV SIGNALITI	PSIGN	00 95969 07282 3
54200M03	TV signal generator (multi standard)	676822	54200M03/001,TV SIGNALITI	PSIGN	00 95969 07290 8
54200N01	TV signal generator (single standard)	627759	54200N01/001,TV SIGNALITI	PSIGN	00 95969 05158 3
54200P01	TV signal generator (single standard)	627858	54200P01/001,TV SIGNALITI	PSIGN	00 95969 05168 2
54200PN1	TV signal generator (dual standard)	676940	54200PN1/001,TV SIGNALITI	PSIGN	00 95969 07314 1
PM5414V-1	TV pattern generator	945571	PM5414V-1,VIDEO GENERITI	PSIGN	00 95969 02371 9
PM5414VY-1	TV pattern generator	945576	PM5414VY-1,PM5414V+Y/ITI	PSIGN	00 95969 02372 6
PM5415-1	TV pattern generator	945584	PM5415-1,TV SIGNAL GENITI	PSIGN	00 95969 02373 3
PM5415TX-1	TV pattern generator	945589	PM5415TX-1,PM5415 + TXITI	PSIGN	00 95969 02374 0
PM5415TXY-1	TV pattern generator	945613	PM5415TXY-1,PM5415TX+ITI	PSIGN	00 95969 02379 5
PM5415Y-1	TV pattern generator	945605	PM5415Y-1,PM5415+Y/C+ITI	PSIGN	00 95969 02378 8
PM5418-1	TV pattern generator	945634	PM5418-1,TV SIGNAL GENITI	PSIGN	00 95969 02383 2
PM5418TDS-1	TV pattern generator	137778	PM5418TDS-1,PM5418TD+ITI	PSIGN	00 95969 03763 1
PM5418TDSIY1	TV pattern generator	137786	PM5418TDSIY1,PM5418TDITI	PSIGN	00 95969 03765 5
PM5418TDSY-1	TV pattern generator	137783	PM5418TDSY-1,PM5418TDITI	PSIGN	00 95969 03764 8
PM5418TX-1	TV pattern generator	945639	PM5418TX-1,PM5418+TXITI	PSIGN	00 95969 02384 9
PM5418TXY-1	TV pattern generator	945662	PM5418TXY-1,PM5418TX+ITI	PSIGN	00 95969 02389 4
PM5418Y-1	TV pattern generator	945659	PM5418Y-1,PM5418+Y/C+ITI	PSIGN	00 95969 02388 7
TV Generators					
Options/Accessories					
54091	Rackmount Kit (54000 series)	625209	54091,RACKMOUNT 3E OPITI	PSIGN	00 95969 05088 3

Typ	Fluke Industrial				
PM9546	Universal chroma unit (TV pattern generators)	862347	PM9546, UNIVERSAL CHROITI	PSIGN	00 95969 10404 3
PM9553G	Y/C and RGB outputs (TV pattern generators)	945837	PM9553G, Y/C+RGB OPT, 5-ITI	PSIGN	00 95969 02440 2
Options and Accessories General					
PAC33	Printer adapter cable (serial to parallel)	624921	PAC33, PRINT ADAPT. CABLITI	PSCOP	00 95969 05047 0
PM8918/301	Low Pass Filter Probe	935101	PM8918/301, LOW PASS (4SCM	SMACC	00 95969 02235 4
PM9001/002	Probe (15 MHz, 1:1)	670718	PM9001/002, X 1 PASSIVE ITI	PSCOP	00 95969 06922 9
PM9001/202	Probe (12 MHz, 1:1)	670729	PM9001/202, X 1 PASSIVE ITI	PSCOP	00 95969 06924 3
PM9003/001	Probe extension set	915988	PM9003/001, SET/TEST LE. ITI	PSCOP	00 95969 10538 5
PM9021/002	Probe (200 MHz, 1:1/10:1)	670775	PM9021/002, X1/X10 PASS ITI	PSCOP	00 95969 06933 5
PM9581	Terminator (50 Ohm, 1W)	102769	PM9581/011, PM9581/01 5ITI	PKIST	00 95969 10405 0
PM9584	Signal Splitter (50 Ohm, 3W)	102777	PM9584/021, PM9584/02 5ITI	PKIST	00 95969 10406 7
PM9585	Terminator (50 Ohm, 3W)	102785	PM9585/011, PM9585/01 5ITI	PKIST	00 95969 10426 5
PM9588/011	BNC cable set (50 Ohm)	102793	PM9588/011, PM9588/01 CITI	PKIST	00 95969 10407 4
SW33W/012E	FlukeView CombiScope software (English)	657210	SW33W/012E, FLUKEVIEW ITI	PSCOP	00 95969 06211 4
RCL Meters					
PM6303A/01	RCL meter (1 kHz)	925750	PM6303A/01, 220V AUTOMITI	PSIGN	00 95969 01746 6
PM6304/001	Programmable RCL meter (DC-100 kHz)	933098	PM6304/001, 220V PROGR. ITI	PSIGN	00 95969 02035 0
PM6304/021	Programmable RCL meter (DC-100 kHz)	933101	PM6304/021, 220V PM6304ITI	PSIGN	00 95969 02036 7
PM6304/031	Programmable RCL meter (DC-100 kHz)	933106	PM6304/031, 220V PM6304ITI	PSIGN	00 95969 02037 4
PM6304/041	Programmable RCL meter (DC-100 kHz)	933114	PM6304/041, 220V PM6304ITI	PSIGN	00 95969 02038 1
PM6304/061	Programmable RCL meter (DC-100 kHz)	933119	PM6304/061, 220V PM6304ITI	PSIGN	00 95969 02039 8
PM6304/071	Programmable RCL meter (DC-100 kHz)	933122	PM6304/071, 220V PM6304ITI	PSIGN	00 95969 02040 4
PM6304/501	Programmable RCL meter (DC-100 kHz)	933127	PM6304/501, 220V PM6304ITI	PSIGN	00 95969 02041 1
PM6304/521	Programmable RCL meter (DC-100 kHz)	933130	PM6304/521, 220V PM6304ITI	PSIGN	00 95969 02042 8
PM6304/531	Programmable RCL meter (DC-100 kHz)	933135	PM6304/531, 220V PM6304ITI	PSIGN	00 95969 02043 5
PM6304/541	Programmable RCL meter (DC-100 kHz)	933143	PM6304/541, 220V PM6304ITI	PSIGN	00 95969 02044 2
PM6304/561	Programmable RCL meter (DC-100 kHz)	933148	PM6304/561, 220V PM6304ITI	PSIGN	00 95969 02045 9
PM6304/571	Programmable RCL meter (DC-100 kHz)	933150	PM6304/571, 220V PM6304ITI	PSIGN	00 95969 02046 6
PM6306/021	Programmable RCL meter (DC-1 MHz)	611001	PM6306/021, PROG. RCL MITI	PSIGN	00 95969 04506 3
PM6306/031	Programmable RCL meter (DC-1 MHz)	611050	PM6306/031, PROG. RCL MITI	PSIGN	00 95969 04511 7
PM6306/061	Programmable RCL meter (DC-1 MHz)	611100	PM6306/061, PROG. RCL MITI	PSIGN	00 95969 04516 2
PM6306/071	Programmable RCL meter (DC-1 MHz)	611159	PM6306/071, PROG. RCL MITI	PSIGN	00 95969 04521 6
PM6306/521	Programmable RCL meter (DC-1 MHz)	611209	PM6306/521, PROG. RCL MITI	PSIGN	00 95969 04526 1
PM6306/531	Programmable RCL meter (DC-1 MHz)	611258	PM6306/531, PROG. RCL MITI	PSIGN	00 95969 04531 5
PM6306/561	Programmable RCL meter (DC-1 MHz)	611308	PM6306/561, PROG. RCL MITI	PSIGN	00 95969 04536 0

Typ	Fluke Industrial				
PM6306/571	Programmable RCL meter (DC-1 MHz)	611357	PM6306/571,PROG. RCL MITI	PSIGN	00 95969 04541 4
RCL Meters Options/Accessories					
PM9536/041	RS-232 cable (RCL meters)	933023	PM9536/041,RS232 CABLEITI	PSIGN	00 95969 01964 4
PM9540/BAN	4-wire test cable set (RCL meters)	115466	PM9540/BAN,4-WIRE TESTITI	PSIGN	00 95969 04273 4
PM9540/TWE	SMD tweezers (RCL meters)	114626	PM9540/TWE,SMD TWEEZITI	PSIGN	00 95969 04070 9
PM9541B	4-wire kelvin clips (RCL meters)	655958	PM9541B,KELVIN CLIP CAITI	PSIGN	00 95969 06170 4
PM9542A	Test fixture (RCL meters)	925763	PM9542A,RCL TEST ADAPITI	PSIGN	00 95969 01748 0
PM9542SMD	Test fixture for SMD (RCL meters)	852350	PM9542SMD,SMD TEST FIITI	PSIGN	00 95969 10403 6
PM9548	GPIB interface (RCL meters)	895081	PM9548,IEEE INTERFACE IITI	PSIGN	00 95969 10531 6
PM9549	RS-232 interface (RCL meters)	933007	PM9549,RS-232 INTERFACITI	PSIGN	00 95969 01939 2
PM9559B	Remote programmer (RCL meters)	1276626	PM9559B,REMOTE PROGRITI	PSIGN	00 95969 07727 9
PM9564	Rackmount kit (RCL meters)	933002	PM9564,RACK MOUNT KITITI	PSIGN	00 95969 01938 5
PM9565	DC measurement option (RCL meters)	932996	PM9565,DC MEASUREMENTITI	PSIGN	00 95969 01937 8
PM9566	Handler interface kit (RCL meters)	932991	PM9566,HANDLER INTERFITI	PSIGN	00 95969 01936 1
SW63W/011E	ComponentView software	611597	SW63W/011E,COMPONENTITI	PSIGN	00 95969 04609 1

ig.

ing.

ong.

ower Recorder. Jaw opening 0.78", 20mm.

Power Recorder. Jaw opening 0.78", 20mm.

order. Jaw opening 1.25", 32mm

